



# **iGATE**

## **ADVANCED AVIATION TRAINING DEVICE OPERATOR'S HANDBOOK**

### **Model G500 Series**



## TABLE OF CONTENTS

<b>PREFACE</b>	<b>4</b>
<b>GENERAL DESCRIPTION</b>	<b>5</b>
<b>LICENSE AGREEMENT</b>	<b>8</b>
<b>SITE SPECIFICATIONS</b>	<b>18</b>
<b>FEATURE OVERVIEW</b>	<b>22</b>
<b>HARDWARECONNECTIVITY</b>	<b>24</b>
<b>STARTING UP / SHUTTING DOWN THE IGATE</b>	<b>26</b>
<b>CONTROLS CALIBRATION SCREEN</b>	<b>31</b>
<b>SHUTTING DOWN THE IGATE</b>	<b>33</b>
<b>INITIAL ONFIGURATION</b>	<b>34</b>
<b>NAVIGATION DATABASES</b>	<b>36</b>
<b>ADJUSTING CONTROL SENSITIVITY</b>	<b>40</b>
<b>INSTRUCTOR / OPERATOR STATION (IOS)</b>	<b>42</b>
<b>ELITE MENU STRUCTURE</b>	<b>43</b>
<b>MALFUNCTIONS PAGE OVERVIEW</b>	<b>44</b>
<b>METEO (WEATHER) PAGE OVERVIEW</b>	<b>45</b>
<b>METAR PAGE</b>	<b>46</b>
<b>DATA MODIFICATION PAGE</b>	<b>47</b>
<b>MAP PAGE OVERVIEW</b>	<b>48</b>
<b>CONTROL PAGE</b>	<b>49</b>
<b>INSTRUMENT PAGE</b>	<b>50</b>
<b>PROGRAM FEATURES</b>	<b>51</b>
<b>MAP PAGE COMMANDS</b>	<b>51</b>
<b>MAP INFORMATION</b>	<b>55</b>

<b>REPOSITION AIRCRAFT</b>	<b>56</b>
<b>MULTIPLE ILS CONFLICTS</b>	<b>58</b>
<b>NAVIGATION DATA PAGES</b>	<b>66</b>
<b>METEO (WEATHER) OPERATIONS</b>	<b>93</b>
<b>MALFUNCTIONS PAGE</b>	<b>109</b>
<b>CONTROL PAGE</b>	<b>118</b>
<b>CONFIGURATION PAGE</b>	<b>125</b>
<b>NAV DATA “MODIFICATION PAGE”</b>	<b>131</b>
<b>EXTERNAL VISUAL DISPLAY - GENVIEW™ ONLY</b>	<b>138</b>
<b>GENERAL INSTRUMENTS</b>	<b>140</b>
<b>IPAD CONFIGURATION PAGE</b>	<b>149</b>
<b>CONNECTING FOREFLIGHT® TO ELITE</b>	<b>150</b>
<b>EFS 40 OVERVIEW</b>	<b>151</b>
<b>SHORTCUT CHECKLIST</b>	<b>156</b>
<b>IGATE CONFIGURATION MATRIX</b>	<b>157</b>

## PREFACE

### WARNING

Any unauthorized changes to the iGATE trainer regarding removal, replacement or repositioning of original flight control components, avionics or switches, not in accordance with manufacturer specifications, will void the FAA approval for logging flight time credit. Only ELITE ATD software may be used with this training device for certification purposes. The instructions and limitations detailed in the FAA letter of approval pertaining to this model of advanced aviation training device must be adhered to and kept in close proximity to the trainer. The controlling authority for the use this training device in a Part 61 or 141 or 142 course of instruction is the Federal Aviation Administration, General Aviation and Commercial Division, AFS-810, 800 Independence Avenue, Washington D.C. 20591.

### REVISIONS

For operational purposes, this handbook should be kept in current status with revisions provided with software upgrades or hardware modifications. Revisions to this handbook will be distributed whenever necessary as complete replacements or additions and shall be inserted into the handbook as below:

Revision pages will replace only pages with the same page number. Insert all additional pages in proper numerical order within each section.

Page numbers followed by a small letter shall be inserted in direct sequence with the same common numbered page.



## GENERAL DESCRIPTION

The ELITE iGATE is one of the most highly advanced IFR flight training devices available today with the best “benefit-to-cost” ratio in its class. It is authorized for use in satisfying Tasks/Maneuvers, and Procedures under sections of Title 14 Code of Federal Regulations parts 61 and 141.

The trainer consists of the following components:

**Flight controls with dynamic control loading:** Some versions of iGATE trainers have 3 axis control loading and some have two axis control loaders. Spring dampened systems are also an available option.

**Avionics,** King Silver Crown with GNS or GTN GPS navigation equipment.

**Dual CPUs** (main computer, image generator with sound system). Number of IGs could change due to visual display options.

**Closed fiber glass cockpit with adjustable seat(s).**

**Overhead panels** include aircraft appropriate hardware or simply lighting. Twin and single engine turbine configurations include side panels and AC specific circuit breakers and switches, throttle unit, and single or dual instrument panels.

**External visual display system\***

**Instructor Operator Station** (desk, LCD monitor, keyboard and mouse), iPad tablet or both.

**ELITE Version AATD software.**

***\*Many display options are available and equipment, models and composition may vary.***



iGATE aircraft are “generic in-category” aircraft or aero models with correct performance parameters and systems to practice simulated flight, tasks and procedures under IMC or instrument meteorological conditions. Data modeling and performance characteristics, however, closely represent actual aircraft specifications and performance of several general aviation aircraft. The instrument panel provides life-sized navigation and engine instruments that allow for a correct scan pattern and complete aircraft start up, run up and shut down. The iGATE allows re-configuration of aircraft through interchangeable software, instrument masks, switches and throttle quadrants. Different classes and types (SEL, Complex, MEL and Turbine) are available options.

The Operator, via the IOS, can change the flying environment such as winds, turbulence, icing characteristics, visibility, ceilings and cloud layers. Any aircraft instrument, receiver or system can be failed immediately, realistically or programmed

for a timed failure without interrupting the student's flight. Both weather and malfunctions scenarios can be saved and re-loaded. The software contains utilities to monitor record and replay flights over a map page displaying the horizontal and vertical flight paths in real time. The navigation data may be from the FAA National Flight Data Center (US only), Jeppesen®, NAVTEC® or other provider of approved navigation data. The data includes airways, intersections, published holding patterns, navaids and airports and airport frequencies.

Though designed for instrument training and proficiency, the visual image native to ELITE software (GenView or RealView) is actual satellite digital elevation models with a generic texture showing urban areas, major bodies of water, rivers, railroad tracks and major roadways. Every IFR rated airport over 3,000 feet length and its lighting system is accurately depicted. ELITE is capable of using 3rd party enhanced visual scenery such as P3D and may be included with your training device.

## **COPYRIGHT**

Copyright 1989 - 2018 by ELITE Simulation Solutions,  
Im Schoerli 1 8600 Duebendorf, Switzerland All rights reserved.

Under copyright laws, this manual may not be copied, reproduced or distributed in any form or by any means, in whole or in part, without the written consent of the author: ELITE Simulation Solutions AG. Your rights to the software are governed by the accompanying software license agreement. Every effort has been made to ensure that the information in this manual is accurate. ELITE Simulation Solutions AG is not responsible for printing or clerical errors.

All terms mentioned in this manual that are actually known to be trademarks or service marks are listed below. ELITE Simulation Solutions AG cannot attest to the accuracy of this information. Use of a term in this manual should not be regarded as affecting the validity of any trademark or service mark. All Windows OS (operating systems) are trademarks of Microsoft Corporation. Jeppesen is a trademark of Jeppesen Sanderson Inc. Garmin, GNS 430/530 are trademarks of Garmin International, Inc.



## LICENSE AGREEMENT

The software component of the iGATE training device constitutes a license agreement and not an agreement for sale. A license agreement is a legal agreement between you, the end user (You), and ELITE Simulations Solutions AG “Licensor.” Please read this software license agreement “Agreement” carefully. If you do not agree with the terms and conditions of this Agreement, you should contact ELITE Simulation Solutions AG within 30 days from the invoice date.

**NOTE: The user of this manual is expected to know how to fly an aircraft. It is not designed to teach instrument navigation or serve as a tutorial for starting, running up, flying or shutting down aircraft. It will not describe the purpose or function of all aircraft specific switches, knobs or levers.**

## SOFTWARE OWNERSHIP

1. The enclosed ELITE iGATE software program “Software” and the accompanying written materials are owned by ELITE Simulation Solutions AG, Switzerland, and are protected by United States copyright laws, by laws of other nations, and by international treaties.

### Grant Of License

2. Licensor grants to You the nonexclusive right to use one copy of the Software on the iGATE trainer in accordance with the terms of the Agreement. You may not install the software on a network or on a computer other than the one that came as a component of the iGATE Advanced ATD without express written permission from ELITE Simulation Solutions.

### Restrictions on Use and Transfer

3. You may not use the software on another computer or loan, rent, transfer, or assign them to another user except as part of the permanent transfer of the iGATE aviation training device.

4. You may not copy the Software, except that you may transfer the Software to a single hard disk for backup or archival purposes. You may not copy the written materials.

5. You may permanently transfer the iGATE Software and accompanying written materials (including the most recent update and all prior versions) if you retain no copies and the transferee agrees to be bound by the terms of this Agreement. Such a transfer terminates “Your” license. You may not rent or lease the Software or otherwise transfer or assign the right to use the Software, except as stated in this paragraph.

6. You may not reverse engineer, decompile, modify, disassemble or create derivative works based upon the Software in whole or part.

## Term and Termination

7. This license terminates if you fail to comply with any provision of this Agreement. You agree upon termination to destroy all copies of the program, modifications and merged portions in any form. The original software must remain with the iGATE training device.

## Limited Warranty

8. Licensor warrants that the Software will perform substantially in accordance with the accompanying written materials for a period of 90 days from the date of your receipt of the Software. Any implied warranties on the Software are limited to 90 days. Some states do not allow limitations on duration of an implied warranty, so the above limitation may not apply to You.

9. LICENSOR DISCLAIMS ALL OTHER WARRANTIES, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT, WITH RESPECT TO THE SOFTWARE AND THE ACCOMPANYING MATERIALS. This limited warranty gives You specific legal rights. You may have others, which vary from state to state.

10. LICENSOR'S ENTIRE LIABILITY AND YOUR EXCLUSIVE REMEDY SHALL BE REPLACEMENT OF THE SOFTWARE. Any replacement Software will be warranted for the remainder of the original warranty period or 30 days, whichever is longer. These remedies are not available outside the United States of America.

11. This Limited Warranty is void if failure of the Software has resulted from modification, accident, abuse, or misapplication.



12. IN NO EVENT WILL LICENSOR BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY LOSS OF PROFITS, LOST SAVINGS, OR OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF YOUR USE OR INABILITY TO USE THE SOFTWARE.

Because some states do not allow the exclusion or limitation of liability for consequential or incidental damages, the above limitation may not apply to You.

13. This Agreement constitutes the entire agreement between You and Licensor regarding the Software and supersedes any other information, advice or representation given to You by Licensor or its dealers, distributors agents or employees. This Agreement is governed by the laws of the State of Florida, U.S.A. and Switzerland, whichever is applicable. If any provision of this Agreement is found to be invalid by any court of competent jurisdiction, the balance of this Agreement shall remain in full force and effect.

14. If You have any questions concerning this Agreement or wish to contact Licensors for any reason, please email [info@flyelite.com](mailto:info@flyelite.com) or write to:

ELITE Simulation Solutions AG  
Im Schoerli 1  
8600 Duebendorf, Switzerland  
or

ELITE Simulation Solutions  
5700 Dot Com Court Suite 1010  
Oviedo, Florida 32765

15. U.S. Government Restricted Rights. The Software and documentation are provided with Restricted Rights. Use, duplication, or disclosure by the Government is subject to restrictions set forth in subparagraph (c)

(1) of The Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 or subparagraphs (c)(1)(ii) and (2) of Commercial Computer Software - Restricted Rights at 48 CFR 52.227-19, as applicable.

## iGATE General Description



*Dual control iGATE, Baron 58 Configuration with AHRS and GNS 430W*

### GENERAL DEVICE DESCRIPTION

The power of iGATE trainers is in its versatility and easy conversions to support a myriad of aircraft types, classes and avionics systems. The iGATE platform supports the most popular single engine and multi-engine aircraft, complex, single and twin turbine aircraft. Avionics configurations include the basic DG/ADF, HSI/RMI, EFIS and AHRS displays with support to the G1000, GNS and GTN series of Garmin® GPS navigation systems. All iGATEs support blue-tooth interface with the most popular electronic flight devices such as Foreflight® and JeppView®.



The ELITE iGATE training devices come in closed or open cockpit configurations. Closed cockpits are made from glossy gel-coat fiberglass with windows that fully enclose the pilots. Open cockpits can be table mounted or mounted to a custom platform depending on space available or customer preference. iGATEs come with either single seat or dual seat configuration, with mechanical flight controls, electrical dynamic control loading flight controls or a combination of pitch & roll dynamic control loading with mechanical rudder pedal controls.



*Single control desktop iGATE, C172 RG w/Legacy Instrument Configuration*



*iGATE with Curved Screen*


Aircraft convertibility is only a few minutes process. The masks are removed and replaced via thumb screws on each corner of the masks. Masks are designed for a specific aircraft profile (See **iGATE Conversion Matrix**). The King Air B200 is typically an aircraft specific iGATE because of the side /overhead panels and center console. The twin turbine B200 can only be converted to a single turbine in a Pilatus PC-12 format. Throttles, like the masks, are changed via thumb screws.

Switch panels on the iGATE console and aircraft specific controls located on the center console are quick change via Dzus-style fasteners. Switch panels and throttles connect to the trainers electrical grid via DB-style connectors. After the iGATE aircraft hardware has been changed, the last step is to select the corresponding aircraft on startup. The process is simple and quick. ELITE uses a CanBus system as the brains behind the iGATE . Dedicated USB smart cards control each aspect of the training device.



***Representative instrument masks, throttle and switches conversion kit***

The USB Control Cards are powered through the iGATE electrical system through a commercial USB hub. Power ON indicators are located on the USB hub and on each USB control card for quick diagnosis. Control cards also contain yellow “transmit” lights” which indicate that data is being sent and received. Other than reseating a card or unplugging and replugging a card’s USB cord, no other troubleshooting steps are recommended without the assistance and guidance of an ELITE qualified technician.



***ELITE USB CanBus System***





***Single Seat iGATE Open Cockpit Configuration with one External Visual***



***Dual Control iGATE with Optional Instructor's Cabin and Projection Visual***



***Single Seat Twin Piston iGATE Closed Cockpit Configuration***



***iGATE Dual Control with Center Console***



## SITE SPECIFICATIONS

### ELECTRICAL

Power Requirement: 115 - 240 VAC; 50/60 Hz

Input Current: 2 x 20A circuits (minimum)

Power Consumption: Max 9000 W

**NOTE: A US electrical grounding plug is provided. Outside of USA, an adapter plug and/or power transformer(s) may be required. Additional circuits may be required depending on optional display configurations.**

### ENVIRONMENTAL

Operating environment: Temperature 50° F (10° C) to 95° F (35° C). We recommend air conditioning afforded basic computer and electronic equipment.


Humidity: 20% to 80% non-condensing. 40% to 60% recommended for optimum performance.

### DIMENSIONS

The cockpit footprint dimensions are shown in the following pictures. For the iGATE cockpit plus one TV “out of windshield” visual display, the minimum sized room requirement would be 10 ft. x 10 ft (3.05 m x 3.05 m). Room ingress and egress must be considered plus room for the IOS desk and computer system. Actual room size needed depends on the visual system desired and if an enclosed instructor cabin is required or desired. For example, five each 55 inch LED TV displays are approximately 13 ft wide (3.96 m). A three screen projection system plus instructor cab would require an additional 4 feet in length.



**NOTE:** There are many considerations regarding room size and access to the iGATE final resting location (door sizes, hallway width, hallway to room layout, elevators, stairway configurations to above level floors), special equipment and required manpower. These circumstances require methodical planning and must be discussed and agreed upon prior to delivery and installation. Exact room requirements, building access, plans and additional costs must be discussed in advance or prior to any move or relocation. Contact an ELITE representative for additional details.





*iGATE with 3 screen projection display*



*iGATE with Curved Screen Projection*





*Desktop iGATE Twin Engine w/ G1000 Avionics*



*Cockpit iGATE Twin Engine w/ HSI and RMI*



## FEATURE OVERVIEW

### NAVIGATION DATA

- US navigational databases (optional world data)
- US GenView™ Visual Database (ELITE visual)
- Lockheed Martin P3D Visual Database (optional)
- International and local GPS database (optional updates)
- Add, delete, and modify navigation facilities/ database elements

### AVIONICS, INSTRUMENTATION, AND HARDWARE

- Bendix King Silver Crown Style Avionics
- Garmin GNS 430W, 530W; GTN 650, 750, G1000 navigation
- Legacy Instruments (HSI/RMI, ADF, DME, DG, ADF)
- EFIS (not available on all aircraft)
- E500 AHRS “glass” display (not available on all aircraft)
- Autopilot / flight director
- Altitude/vertical speed preselect; annunciator panel
- Radar altimeter (not available on all aircraft)
- Dynamic Control Loading (Optional)
- Single and dual pilot; open or closed cockpit or desktop solutions
- Interchangeable masks, switches, throttles and software (purchase)

**NOTE: See iGATE Configuration Matrix page 157 in this manual for specific aircraft equipment and component possibilities.**

### WEATHER

- Advanced static and/or dynamic weather modeling
- Fully programmable wind, turbulence, visibility, clouds, temperature, pressure and icing
- Downloadable METAR reports and integrated real time weather
- Create and save an unlimited number of weather “state” files

## MALFUNCTIONS

- Fully programmable instrument, power plant, avionics, gear, and system failures
- Set immediate, timed, gradual, and random failures
- Accurately modeled insidious failure behavior
- Virtual instrument covers (for partial panel work)
- Create and save an unlimited number of malfunction “state files”.

## MAPPING AND EVALUATION

- Plan, profile and extended profile views
- Gear/ flap position graph and airspeed plot
- Flight Data Recorder with VCR-style playback control
- Virtual airport facility directory
- Transponder tag w/squawk code, heading and altitude readout
- “Spot WX” station model display symbology (wind, temp, visibility and pressure display)
- Quick “click and drag” aircraft repositioning
- Real time and/or recorded flight instrument presentation on IOS Map Screen
- Route planner
- Heading/Distance MAP cursor (instant E6B-style calculations)
- Instrument Approach Scenarios (optional)
- Print, save, and replay and unlimited number of aircraft “path” files
- Create and save an unlimited number of aircraft “state” files




## iGATE HARDWARE CONNECTIVITY

Because the iGATE uses PC-based technology, the connection of simulator components from computers to the trainer and visual is typical of home computer, video and audio connections. This makes troubleshooting and diagnosis very simple. ELITE uses USB and a commercial USB hub to connect various masks, switches, levers, throttles and pedals to the HOST computer. Video cables connect the Instrument Monitors to the HOST Computer. The Visual Computer (aka Image Generator(s)) is connected to the HOST computer via LAN cable and has (video cable(s) to the main LCD display(s).

**NOTE: When the HOST computer is connected to the Internet, ELITE technicians have the ability to perform a remote log-in and conduct software upgrades, make adjustments and diagnose issues. DO NOT CONDUCT REPAIRS WITHOUT CONSULTING AN ELITE TECHNICIAN!**

Exact layout may vary according to visual display system but the concept is the same.



*iGATE Simplified Layout*

The ELITE or P3D visual scenery can be shown on any device that will receive a computer signal (i.e. TVs, monitors, projectors). The HOST and VISUAL computers are custom built and configured for the iGATE. Multiple displays may be used to achieve up to 220 degree fields of view. Do not modify the display(s) or replace components without consulting an ELITE technician. Performance, visual correctness and approval authority may be jeopardized.

### **NOTE: USB WIBU KEY**

The WIBU Key is a dongle that contains the serial number to the simulator's software. If this key is missing, malfunctioned or the WIBU key driver is missing or corrupted, the simulation will stop in 3 minutes! If the simulator freezes in 3 minutes, the WIBU key is missing, the key has malfunctioned or the USB hub has stopped working. The WIBU key is typically located inside the iGATE console plugged into the commercial USB hub. It may be plugged into the HOST computer. If the key is recognized and operating properly, it should be identified in the Windows Device Manager. Contact ELITE for additional support if needed.



**WIBU Key (Black or Green Color)**

## IGATE STARTUP AND SHUTDOWN

**NOTE:** UPSs (Uninterrupted Power Supplies) are essential to the protection of your iGATE's electrical equipment! The UPS provides battery backup protection in the event of a power failure and allows an orderly shutdown of equipment. It also provides surge protection in a storm event and filters unstable power. The number of UPS for the iGATE depends on the power requirement for a specific configuration. For example, if multiple TVs or projectors are used for the visual display, an additional UPS would be required. For one to two computers plus one TV or projector, one UPS would suffice.


Apply power to the iGATE system by pressing the UPS power button: **NOTE: The UPS should be the first to POWER ON and the last to POWER OFF.**

Press for ON or OFF





## IGATE MASTER CONTROL MODULE



After power is applied to the iGATE, the above ELITE Master Control Module will appear on the Instructor Operator Station (IOS) monitor after computer boot up is complete.


- A. Button to LAUNCH all software.
- B. Reboot all computers or SHUT DOWN all computers.
- C. Reboot or shut down SELECTED computers.
- D. Shows Computers ON LINE in green or OFF LINE in red.
- E. HELP button takes you to ELITE web Support if computer(s) fail to come on line after reboot.

## PRE STARTUP NOTICE

1. Make sure there is no one in the cockpit!
2. For iGATESs with Control Load (CL) flight controls, check that the Emergency Stop is in Neutral position (yellow ring between the red knob and Emergency Stop decal visible)!



*Emergency Stop Switch*



*Center Console Emergency Stop and Freeze Button Location*

**NOTE:** In the event that the CL flight controls move erratically or uncontrollably during startup or operation, twist the red emergency stop handle to the right to disengage power from the CL flight controls.



The iGATE MAIN computer has a memory program that is designed to restore original iGATE settings when shut down and rebooted. For example, if the instrument panel(s), IOS and engine instrument panels have been re-arranged by the Windows OS, you can restore the original settings by shutting down the MAIN computer and re-starting it.

## STARTING THE iGATE


1. Press the LAUNCH ELITE icon on the IOS Master Control Module.

**Control Loaded flight controls (pitch, roll and/or yaw) will motor through the full range of operation and return to its neutral position. Allow the controls to move on their own accord... do not interfere with its internal calibration!**

2. Choose the aircraft intended to fly by double-clicking on the icon or high lighting the icon and clicking on CHOOSE.



**NOTE: One or more aircraft profiles could be shown for selection. Double click mouse on the icon or high light the icon and press CHOOSE.**




3. **Choose your navigation database** by highlighting your desired navigation area and clicking “choose” or double clicking on the navigation area icon. The main computer will connect or communicate with the image generator and you will see the aircraft position itself... first an aerial view then positioning on a runway threshold. The instrument and engine gauges will appear.

**NOTE: CL (Control Loaded) flight controls (yoke and/or rudder pedals perform a self-calibration. Non CL controls Calibration is conducted at the factory and this step may be unnecessary. Calibrate only if necessary!**

4. Before the first flight, it is important to calibrate the flight controls. This is a simple exercise to teach the software the range of values from the pitch, roll, yaw, brake and throttle movements. This calibration is only required for the first flight and in the event that the flight controls have been disconnected and reconnected (ie. device has moved). To calibrate the flight controls:

- Bring up the program menu selections on the instructor monitor (right mouse click anywhere on the screen).
- Choose CONFIGURATION
- Left mouse click on CONTROLS CALIBRATION
- Follow on-screen instructions to calibrate the controls
- Click OK to continue when finished.



## CONTROLS CALIBRATION SCREEN

*Press HELP and follow instructions*

## FAA Notification Requirement


The FAA has two notification requirements on startup. The software will test vital components (aileron, elevator, rudders, power quadrant and avionics in accordance with AC 61-136A. are tested on startup. ALL GREEN indicates that components are functioning properly. Failures are indicated with red. A red-lettered component will not allow the program to continue. Press QUIT then REBOOT ALL at the IOS Master Control Module. If the problem remains, contact ELITE technical personnel.

**WARNING:**  
Changes or modifications to the original ELITE Advanced ATD hardware configuration as defined in the Elite Simulation Solutions Qualification Guide, AC 61-136, will disqualify this device for credit.

**All tests passed according AC 61-136.**

Aileron, Elevator, Rudder detected and working.  
Power quadrant is detected and working properly.  
Avionics Panel is detected and working.


The second notification is a reminder that simply states that if the training session is used for instrument experience or currency, the weather in the visual scenery must be set to IMC until reaching Decision Height, Decision Altitude or Minimum Descent Altitude.



The flight controls, switches, levers and knobs perform the same function as their counterpart in the real aircraft. At this point you can change frequencies, adjust instruments and perform all procedures for flight as you would in the actual aircraft. The flight may be paused at any time by pressing the FREEZE button on the center console avionics panel or by using the main screen (Instructor / Operator screen) menu FREEZE selection.




OR



## SHUTTING DOWN THE IGATE


Proper shutdown of the iGATE computer systems must be done from the Instructor/Operator Station (IOS) screen.

1. Quit the ELITE program (ALT Q shortcut or QUIT on menu dialog box) to the desktop.
2. At the SCADA Client dialog box, click SHUTDOWN ALL
3. When all computers have completed their automatic shutdown, turn the system power off by hold the UPS power button.



**NOTE: DO NOT turn the power off to the instrument panels, LCD monitors, or TVs. Projectors are the only components that should be turned off separately because of cooling requirements. To remove power completely from the system, simply turn the power off at the Battery Backup (UPS). Hold in until power turns off.**

Press for ON or OFF





## INITIAL CONFIGURATION: THE CONFIGURATION PAGE

It is recommended that this page be reviewed carefully. After configuring to your satisfaction, press the SAVE button (RIGHT TOP CORNER) to keep all values. These selections are stored in a PREF folder in the program directory. These values will be read when starting the program. Once set, you will seldom need to go to this page. The instructor or operator can set a password to prevent access to the Configuration Page.

Certain features of the aircraft can be changed or configured to personal preference or training requirement. An example of Configuration was the control calibration performed as described above.

You get to the CONFIGURATION PAGE by right mouse clicking on the instructor's monitor when ELITE is running. This brings up the ELITE Main Menu. **Click on CONFIGURATION PAGE or use the keyboard shortcut "alt G".**

### Box 1: GENERAL SETTINGS

Under General Settings, clicking the SET button opens a dialog box that lets you customize features in the startup sequence, set/change pass words, set LT/UTC offset, toggle ATD detection report, and activate failure control from the keyboard. These settings are retained until changed or reset.



The Configuration Page consists of nine sections as shown: General Settings (1), Hardware Configuration (2), Controls (3), Units (4), Handling (5), Color for Digits (6), Aircraft Information (7), Sounds (8) and Instrument (9). This section will cover the basics to custom configure the iGATE. Other information from this screen will be covered in Chapter Two.

## CONFIGURATION PAGE DESCRIPTION


The screenshot shows the CONFIGURATION PAGE with the following sections and settings:

- General settings:** Stick: Standard (1)
- Hardware Configuration:** Computer: SET (2), Elite Hardware: SHOW
- Controls:** Calibration: SET, Dampening: 0.00 (3), Roll: 0.00 (4), Yaw: 0.00 (5), SAVE
- Units:** Weight: LBS (6), %Tot F, %Fuel T, LITRE, US G, IMP G
- Handling:** Ask before: YES (7), SAVE state files: DISABLE
- Color for Digits:** RED (8), YELLOW
- Menu Pos:** 1st - Startup, Screen: 2ND - 2ND
- Aircraft Reposition:** Rwy Offset: 0 ft
- Aircraft Information:** NEW ACFT MODULE, Aircraft module: Archer3FullHD.pho, Aircraft: Archer III FullHD (v1), Engines: 1, Rated power: 180 HP, Propeller: Fixed pitch, Service ceiling: 14000 ft, Gear: Fixed, Gross weight: 1158 kg, Empty weight: 826 kg, Usable fuel: 49.0 US gal, 130.7 kg, Speed: Never exceed speed: 154 kts, Best single engine rate of climb: --- kts, Minimum single engine control speed: --- kts, Maximum structural cruising speed: 125 kts, Zero flaps stalling speed: 50 kts, Flaps extended stalling speed: 45 kts, Maximum speed for flaps extended: 102 kts, Maximum speed for gear extended: --- kts, Maximum speed for gear operation: --- kts
- Sounds:** Intro: ON, Engine: ON (9), Flaps: ON (10), IAS: ON (11), Cockpit: ON (12), 3D Sound: OFF, Idents: 100
- Instrument Configuration:** Resolution: Archer 3 (D0), 16:9, ADF indicators: Bendix/King 227-00 ADF, Carburetor Heat: No Hardware (13), Fuel selector: No external selector, Fuel boost/Pitot switch: External switch, CDI 2 Indicators: CDI 2 without GS

The **CONFIGURATION Page** is used to:

- set ELITE start up preferences
- adjust control sensitivity (spring mechanisms only)
- change units of measurement for fuel and weight
- turn sounds on/off; adjust volume levels
- calibrate flight control devices (NOT FOR CONTROL LOAD)
- load new aircraft modules
- save instrument configurations where applicable.

Aircraft operational characteristics and limitations are also shown (but cannot be modified).




## NAVIGATION DATABASES

When “Ask for Navigation Databases at program start” button is ON, ELITE will ask (on every startup) to select a NAV database area to fly in. **“Easy open of Navigation databases” allows you to choose a NAV area by viewing thumbnail maps of all available individual navigation areas installed.**

**NOTE:** To have ELITE automatically start up (default) to the same aircraft and NAV area each time, first make sure you are currently using the NAV area you would like for subsequent startups, then turn OFF “Ask for Navigation data bases at program start” buttons.

### Box 2: HARDWARE CONFIGURATION.

**CHANGING SYSTEM SETTINGS:** Do NOT USE Changing System Settings unless instructed to do so by ELITE Technical Support personnel.




***Adjustments to System Settings can render the iGATE inoperative!***



## FLIGHT CONTROLS CALIBRATION & DAMPING

Calibration is necessary to bring the iGATE flight controls (yoke, pedal and throttle system) controls (NON CL!) into proper tolerances and allow ELITE to learn the limits of the of the controls. (Pressing the HELP button in the Calibration dialog box will open on screen instructions and walk you through the calibration process.) NOTE: Control loading on pitch, roll and yaw do not require calibration.

Under Controls click the SET button next to calibration. The Calibration screen is divided into three sections or “panels.” From left to right these are; Limits, Null zone, and Helicopter respectively. Follow these instructions to properly calibrate your flight control device(s):



## LIMITS

Under Limits, click the **RESET** button. Now move your non CL controls through their FULL range of motion, i.e. left, right, forward and backward to the stops. The cross-hairs have now traced a blue box graphically representing the limits of the control device being used. Next apply FULL left and right rudder pedal. You will see a small vertical line move with the application of pedal input. Click **SET** to store the new limits settings.

## NULL ZONE (NON CONTROL LOADED ONLY)

The center Null Zone panel allows the user to define a “box” within which the non CL control device(s) is considered centered. If a flight control does not physically return exactly to center but is still within the limits of the “box” under the Null Zone panel, no flight command input will be sent to the software. Some experimentation with different Null zone settings may be necessary to achieve optimum control response. In general, larger Null zones require greater flight control travel accompanied by a coincident perceived decrease in sensitivity. Under Null Zone, click RESET. Press the “R” key on your key board and move the cyclic to adjust the size of the (Roll) Null zone. To accept and store this setting hit ENTER or press the “S” key to return to the previously stored value. Next, press the “P” key on your keyboard and move the cyclic to adjust the size of the (Pitch) Null zone. To accept this setting hit ENTER or press the “S” key to return to the previously stored value. Next press the “Y” key on the key board and move the pedals to adjust the width of the of the (Yaw) Null zone.



**NOTE:** Clicking the RESET button returns ALL Null zone settings to default. Individual Null zones can be adjusted without clicking RESET by simply pressing “R”, “P”, or “Y” keys respectively.

## igATE POWER QUADRANT

Under Quadrant, click **RESET**. Now physically move all levers to their halfway or 50% position.

Do NOT use lines on the IOS screen for reference! Once levers are positioned physically at 50% (on device) click the middle SET button next to the 50% marking on screen.

Calibration is now complete! Click OK to save these settings & return to the Configuration page, or CANCEL to return and revert to previous settings without saving. Quit and restart ELITE for new calibration settings to take effect.




*Piper-style SEL Complex & MEL replaceable throttle quadrants (top)  
Vernier-style SEL Complex & Simple (bottom)*

Real aircraft are inherently stable, simulators are not. For in experienced simulator pilots, the most common difficulty is over controlling or getting used to the control sensitivity.

Practice basic flying maneuvers as you would in any new air craft transition before starting your IFR practice. Remember “the less is more” adage and make small pitch and roll corrections for variation in altitude and/or heading. Do NOT chase the VSI. Monitor instrument/needle trend, not just movement. This makes for smooth, precise, instrument flight and prevents awkward action/ reaction responses.

## USB BUTTON



*Press “USB” button to see ELITE USB hardware connected*

## ADJUSTING CONTROL SENSITIVITY:

### NON CL FLIGHT CONTROL ONLY!

Increase or decrease numbers in the P, R, Y boxes to adjust control sensitivity. Start with low to mid-range. Yaw usually requires more dampening than pitch or roll.



*Numbers between 0.00 (no dampening) and 0.20 (maximum dampening) change the sensitivity of flight control devices.*

## SECOND MONITOR:

Pressing the 2ND SCREEN button assigns program menu to the 2nd monitor. This allows someone sitting at the instructor's station easier access to the program menu and features.




the

## INSTRUMENT CONFIGURATION

The Instrument Configuration panel is different for each aircraft module depending on the cockpit resolution(s), instrument configurations, power units, and external switches unique to that module.

Clicking on a black arrow opens a drop-down menu displaying all available (changeable) options for that section. Drag the finger tip to the option desired and release the mouse button to make your selection. The selected option will be indicated, replacing the previous selection.



**NOTE:** Some options may NOT be available even though there is a configuration option! Contact ELITE if there are any doubts.

King 229 RMI Indicator ▼

◆ King 229 RMI Indicator  
King 227 ADF Indicator ▼

**NOTE: DO NOT MAKE CHANGES TO INSTRUMENT CONFIGURATIONS WITHOUT DIRECTION FROM ELITE TECHNICAL SPECIALISTS!**



# INSTRUCTOR / OPERATOR STATION (IOS)

## MENU DESCRIPTION AND OVERVIEW

When the instruments are displayed in the cockpit and the external visual displays shows a runway, the IOS LCD monitor will depict a map screen. From here, the operator can access all areas of the program through a MENU system. A brief over view of the MENU items follow:

### PROGRAM MENU

After starting the program, you will enter the simulation in the cockpit (in front of the Instrument panel).

**The MENU button at the bottom right of your instructor screen is your access to the many features.**



Click and hold on the MENU button to open the menu. While holding your mouse button, move the cursor to the menu selection and release. As you move through each selection, the item to be opened will be highlighted. **Keyboard shortcuts are listed beside their corresponding menu item.** For shortcuts, hold the key board ALT key and the designated letter. CAPS Lock should be OFF.

**An alternative method of opening the MENU dialog box is to RIGHT MOUSE CLICK anywhere on the screen (except the visual scenery).**

**NOTE: The simulation is in the FREEZE mode if Menu or FREEZE is colored red.**

## ELITE MENU STRUCTURE

The following is only an overview of the MENU layout. For detailed capabilities and operations, see Program Features.

QUIT	ALT Q	→ <b>Exit Program</b>
iPad Configure	ALT Y	→ <b>iPad Configuration</b>
MALFUNCTIONS	ALT S	→ <b>Malfunction Page</b>
METAR	ALT R	→ <b>Active METAR</b>
METEO	ALT W	→ <b>Weather Page</b>
MODIFICATION	ALT D	→ <b>Data Modification</b>
CONFIGURATION	ALT G	→ <b>Configuration Page</b>
MAP	ALT M	→ <b>MAP Page</b>
CONTROL	ALT C	→ <b>Control Page</b>
INSTRUMENT	ALT I	→ <b>Instrument Panel</b>
HELP	ALT H	→ <b>Help Tips</b>
<b>FREEZE</b> Menu	<b>ALT F</b>	→ <b>Freeze / Unfreeze</b>

**NOTE:** Keyboard shortcuts are shown to the right of menu title (for example, ALT Q on the keyboard will exit the program).

Shortcuts save time and allow instructor to change menus without alerting the student. Clicking on menu page will FREEZE simulation.

## MALFUNCTIONS PAGE

The MALFUNCTIONS Page is used to initiate failures or create failure scenarios. You have the opportunity to selectively or randomly fail individual instruments, systems, avionics, engines, gear, hydraulics and more.

Instruments / Systems	Receivers / Gear / Flaps	Engines	Random Failures
<b>Airdata Computer Failures</b> Airdata Computer <input type="checkbox"/> Arm Altitude <input type="checkbox"/> Arm IAS/TAS <input type="checkbox"/> Arm Vertical Speed <input type="checkbox"/> Arm  <b>AHRS Failures</b> AHRS System <input type="checkbox"/> Arm Pitch/Roll <input type="checkbox"/> Arm Pitch Offset <input type="text" value="00"/> <input type="button" value="-"/> <input type="button" value="+"/> Roll Offset <input type="text" value="00"/> <input type="button" value="-"/> <input type="button" value="+"/> Slip Rate <input type="checkbox"/> Arm Turn Rate <input type="checkbox"/> Arm Magnetic Heading <input type="checkbox"/> Arm  <b>Sbby. Instrument Failures</b> Freeze Gradual Sbby. Altitude Indicator <input type="checkbox"/> Arm <input type="checkbox"/> Arm Pitch Offset <input type="text" value="00"/> <input type="button" value="-"/> <input type="button" value="+"/> Roll Offset <input type="text" value="00"/> <input type="button" value="-"/> <input type="button" value="+"/> Sbby. Altitude Indicator <input type="checkbox"/> Arm <input type="checkbox"/> Arm Sbby. Speed Indicator <input type="checkbox"/> Arm <input type="checkbox"/> Arm  <b>System Failures</b> Instruments <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm Static <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm Pitot Inlet Freeze <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm Pitot System Freeze <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm Electric System <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm	<b>Receiver Failures</b> Immediate Timed Between (min.) NAV 1 REC <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm CDI LOC <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm GS <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm NAV 2 REC <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm CDI LOC <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm GS <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm DME <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm ADF <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm Aux. Feeds <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm SPDR <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm  <b>Gear/Flaps Failures</b> Arm Gear <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm Arm Flaps <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm  <b>Misc. Failures</b> Fuel Leaks <input type="checkbox"/> Arm Left Fuel Tank <input type="checkbox"/> Arm Right Fuel Tank <input type="checkbox"/> Arm	<b>Engine Failures</b> Immediate Timed Between (min.) Left Engine Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm Left Engine Power Loss <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm Oil Temp <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm Oil Temp <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm Power <input type="text" value="100"/> % Right Engine Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm Right Engine Power Loss <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm Power <input type="text" value="100"/> % Right Auxiliaries Oil Press <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm Oil Temp <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm Oil Temp <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm	<b>Random Failures</b> Instruments Between (min.) Instruments <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm Systems Between (min.) Systems <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm Receivers Between (min.) Receivers <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm Gear/Flaps Between (min.) Gear/Flaps <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm Engines Between (min.) Engines <input type="checkbox"/> Arm <input type="checkbox"/> Arm <input type="checkbox"/> Arm


**NOTE: Malfunction choices are aircraft specific and will vary according to the aircraft class and type.**

# METEO (WEATHER) PAGE

Weather for Visual		Actual Weather at current position		Weather for Visual		Actual Weather at current position	
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 1	Coverage: 0.0	Wind 10000 ft HSL and above	Direction (° True): 000 To: 360	Wind 10000 ft HSL and above	Wind direction (True): 000
Top Cloud Layer	Coverage: 0.0 To: 10.0	Cloud Layer 2	Coverage: 0.0	Speed (kts)	From: 0.0 To: 200.0	Wind direction (True)	Speed: 0.0 kts
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 3	Coverage: 0.0	Turbulence	From: 0.0 To: 200.0	Wind direction (True)	Turbulence: 0.0
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 4	Coverage: 0.0	Wind from 5000 ft HSL to 10000 ft HSL	Direction (° True): 000 To: 360	Wind from 5000 ft HSL to 10000 ft HSL	Wind direction (True): 000
Transmittance	From: 0.0 To: 1.0	Cloud Layer 5	Coverage: 0.0	Speed (kts)	From: 0.0 To: 200.0	Wind from 5000 ft HSL to 10000 ft HSL	Speed: 0.0 kts
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 6	Coverage: 0.0	Turbulence	From: 0.0 To: 200.0	Wind from 5000 ft HSL to 10000 ft HSL	Turbulence: 0.0
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 7	Coverage: 0.0	Wind from Ground to 5000 ft HSL	Direction (° True): 000 To: 360	Wind from Ground to 5000 ft HSL	Wind direction (True): 000
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 8	Coverage: 0.0	Speed (kts)	From: 0.0 To: 200.0	Wind from Ground to 5000 ft HSL	Speed: 0.0 kts
Transmittance	From: 0.0 To: 1.0	Cloud Layer 9	Coverage: 0.0	Turbulence	From: 0.0 To: 200.0	Wind from Ground to 5000 ft HSL	Turbulence: 0.0
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 10	Coverage: 0.0	QNH (kPa)	From: 0.0 To: 10.0	QNH (kPa)	QNH (kPa): 0.00
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 11	Coverage: 0.0	QNH (hPa)	From: 0.0 To: 10.0	QNH (hPa)	QNH (hPa): 0.00
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 12	Coverage: 0.0	Temperature (°C Sea)	From: 0.0 To: 10.0	Temperature (°C Sea)	Temp (SEA): 0.0 °C
Transmittance	From: 0.0 To: 1.0	Cloud Layer 13	Coverage: 0.0	Temperature (°C Air)	From: 0.0 To: 10.0	Temperature (°C Air)	Temp (AIR): 0.0 °C
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 14	Coverage: 0.0	Temperature (°C Ground)	From: 0.0 To: 10.0	Temperature (°C Ground)	Temp (GND): 0.0 °C
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 15	Coverage: 0.0	Temperature (°C Surface)	From: 0.0 To: 10.0	Temperature (°C Surface)	Temp (SURF): 0.0 °C
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 16	Coverage: 0.0	Temperature (°C Subsurface)	From: 0.0 To: 10.0	Temperature (°C Subsurface)	Temp (SUBS): 0.0 °C
Transmittance	From: 0.0 To: 1.0	Cloud Layer 17	Coverage: 0.0	Temperature (°C Depth)	From: 0.0 To: 10.0	Temperature (°C Depth)	Temp (DEPTH): 0.0 °C
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 18	Coverage: 0.0	Temperature (°C Ice)	From: 0.0 To: 10.0	Temperature (°C Ice)	Temp (ICE): 0.0 °C
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 19	Coverage: 0.0	Temperature (°C Snow)	From: 0.0 To: 10.0	Temperature (°C Snow)	Temp (SNOW): 0.0 °C
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 20	Coverage: 0.0	Temperature (°C Rain)	From: 0.0 To: 10.0	Temperature (°C Rain)	Temp (RAIN): 0.0 °C
Transmittance	From: 0.0 To: 1.0	Cloud Layer 21	Coverage: 0.0	Temperature (°C Fog)	From: 0.0 To: 10.0	Temperature (°C Fog)	Temp (FOG): 0.0 °C
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 22	Coverage: 0.0	Temperature (°C Haze)	From: 0.0 To: 10.0	Temperature (°C Haze)	Temp (HAZE): 0.0 °C
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 23	Coverage: 0.0	Temperature (°C Smoke)	From: 0.0 To: 10.0	Temperature (°C Smoke)	Temp (SMOKE): 0.0 °C
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 24	Coverage: 0.0	Temperature (°C Dust)	From: 0.0 To: 10.0	Temperature (°C Dust)	Temp (DUST): 0.0 °C
Transmittance	From: 0.0 To: 1.0	Cloud Layer 25	Coverage: 0.0	Temperature (°C Ash)	From: 0.0 To: 10.0	Temperature (°C Ash)	Temp (ASH): 0.0 °C
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 26	Coverage: 0.0	Temperature (°C Sand)	From: 0.0 To: 10.0	Temperature (°C Sand)	Temp (SAND): 0.0 °C
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 27	Coverage: 0.0	Temperature (°C Gravel)	From: 0.0 To: 10.0	Temperature (°C Gravel)	Temp (GRAVEL): 0.0 °C
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 28	Coverage: 0.0	Temperature (°C Rock)	From: 0.0 To: 10.0	Temperature (°C Rock)	Temp (ROCK): 0.0 °C
Transmittance	From: 0.0 To: 1.0	Cloud Layer 29	Coverage: 0.0	Temperature (°C Iceberg)	From: 0.0 To: 10.0	Temperature (°C Iceberg)	Temp (ICEBERG): 0.0 °C
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 30	Coverage: 0.0	Temperature (°C Shipwreck)	From: 0.0 To: 10.0	Temperature (°C Shipwreck)	Temp (SHIPWRECK): 0.0 °C
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 31	Coverage: 0.0	Temperature (°C Aircraft)	From: 0.0 To: 10.0	Temperature (°C Aircraft)	Temp (AIRCRAFT): 0.0 °C
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 32	Coverage: 0.0	Temperature (°C Helicopter)	From: 0.0 To: 10.0	Temperature (°C Helicopter)	Temp (HELICOPTER): 0.0 °C
Transmittance	From: 0.0 To: 1.0	Cloud Layer 33	Coverage: 0.0	Temperature (°C Balloon)	From: 0.0 To: 10.0	Temperature (°C Balloon)	Temp (BALLOON): 0.0 °C
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 34	Coverage: 0.0	Temperature (°C Parachute)	From: 0.0 To: 10.0	Temperature (°C Parachute)	Temp (PARACHUTE): 0.0 °C
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 35	Coverage: 0.0	Temperature (°C Rocket)	From: 0.0 To: 10.0	Temperature (°C Rocket)	Temp (ROCKET): 0.0 °C
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 36	Coverage: 0.0	Temperature (°C Missile)	From: 0.0 To: 10.0	Temperature (°C Missile)	Temp (MISSILE): 0.0 °C
Transmittance	From: 0.0 To: 1.0	Cloud Layer 37	Coverage: 0.0	Temperature (°C Bomb)	From: 0.0 To: 10.0	Temperature (°C Bomb)	Temp (BOMB): 0.0 °C
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 38	Coverage: 0.0	Temperature (°C Grenade)	From: 0.0 To: 10.0	Temperature (°C Grenade)	Temp (GRENADE): 0.0 °C
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 39	Coverage: 0.0	Temperature (°C Shell)	From: 0.0 To: 10.0	Temperature (°C Shell)	Temp (SHELL): 0.0 °C
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 40	Coverage: 0.0	Temperature (°C Bullet)	From: 0.0 To: 10.0	Temperature (°C Bullet)	Temp (BULLET): 0.0 °C
Transmittance	From: 0.0 To: 1.0	Cloud Layer 41	Coverage: 0.0	Temperature (°C Fragment)	From: 0.0 To: 10.0	Temperature (°C Fragment)	Temp (FRAGMENT): 0.0 °C
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 42	Coverage: 0.0	Temperature (°C Debris)	From: 0.0 To: 10.0	Temperature (°C Debris)	Temp (DEBRIS): 0.0 °C
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 43	Coverage: 0.0	Temperature (°C Wreckage)	From: 0.0 To: 10.0	Temperature (°C Wreckage)	Temp (WRECKAGE): 0.0 °C
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 44	Coverage: 0.0	Temperature (°C Remains)	From: 0.0 To: 10.0	Temperature (°C Remains)	Temp (REMAINS): 0.0 °C
Transmittance	From: 0.0 To: 1.0	Cloud Layer 45	Coverage: 0.0	Temperature (°C Bones)	From: 0.0 To: 10.0	Temperature (°C Bones)	Temp (BONES): 0.0 °C
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 46	Coverage: 0.0	Temperature (°C Teeth)	From: 0.0 To: 10.0	Temperature (°C Teeth)	Temp (TEETH): 0.0 °C
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 47	Coverage: 0.0	Temperature (°C Fingers)	From: 0.0 To: 10.0	Temperature (°C Fingers)	Temp (FINGERS): 0.0 °C
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 48	Coverage: 0.0	Temperature (°C Hair)	From: 0.0 To: 10.0	Temperature (°C Hair)	Temp (HAIR): 0.0 °C
Transmittance	From: 0.0 To: 1.0	Cloud Layer 49	Coverage: 0.0	Temperature (°C Skin)	From: 0.0 To: 10.0	Temperature (°C Skin)	Temp (SKIN): 0.0 °C
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 50	Coverage: 0.0	Temperature (°C Blood)	From: 0.0 To: 10.0	Temperature (°C Blood)	Temp (BLOOD): 0.0 °C
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 51	Coverage: 0.0	Temperature (°C Urine)	From: 0.0 To: 10.0	Temperature (°C Urine)	Temp (URINE): 0.0 °C
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 52	Coverage: 0.0	Temperature (°C Sweat)	From: 0.0 To: 10.0	Temperature (°C Sweat)	Temp (SWEAT): 0.0 °C
Transmittance	From: 0.0 To: 1.0	Cloud Layer 53	Coverage: 0.0	Temperature (°C Saliva)	From: 0.0 To: 10.0	Temperature (°C Saliva)	Temp (SALIVA): 0.0 °C
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 54	Coverage: 0.0	Temperature (°C Tears)	From: 0.0 To: 10.0	Temperature (°C Tears)	Temp (TEARS): 0.0 °C
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 55	Coverage: 0.0	Temperature (°C Spine)	From: 0.0 To: 10.0	Temperature (°C Spine)	Temp (SPINE): 0.0 °C
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 56	Coverage: 0.0	Temperature (°C Heart)	From: 0.0 To: 10.0	Temperature (°C Heart)	Temp (HEART): 0.0 °C
Transmittance	From: 0.0 To: 1.0	Cloud Layer 57	Coverage: 0.0	Temperature (°C Lungs)	From: 0.0 To: 10.0	Temperature (°C Lungs)	Temp (LUNGS): 0.0 °C
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 58	Coverage: 0.0	Temperature (°C Liver)	From: 0.0 To: 10.0	Temperature (°C Liver)	Temp (LIVER): 0.0 °C
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 59	Coverage: 0.0	Temperature (°C Kidneys)	From: 0.0 To: 10.0	Temperature (°C Kidneys)	Temp (KIDNEYS): 0.0 °C
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 60	Coverage: 0.0	Temperature (°C Pancreas)	From: 0.0 To: 10.0	Temperature (°C Pancreas)	Temp (PANCREAS): 0.0 °C
Transmittance	From: 0.0 To: 1.0	Cloud Layer 61	Coverage: 0.0	Temperature (°C Spleen)	From: 0.0 To: 10.0	Temperature (°C Spleen)	Temp (SPLEEN): 0.0 °C
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 62	Coverage: 0.0	Temperature (°C Gallbladder)	From: 0.0 To: 10.0	Temperature (°C Gallbladder)	Temp (GALLBLADDER): 0.0 °C
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 63	Coverage: 0.0	Temperature (°C Stomach)	From: 0.0 To: 10.0	Temperature (°C Stomach)	Temp (STOMACH): 0.0 °C
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 64	Coverage: 0.0	Temperature (°C Intestine)	From: 0.0 To: 10.0	Temperature (°C Intestine)	Temp (INTESTINE): 0.0 °C
Transmittance	From: 0.0 To: 1.0	Cloud Layer 65	Coverage: 0.0	Temperature (°C Bladder)	From: 0.0 To: 10.0	Temperature (°C Bladder)	Temp (BLADDER): 0.0 °C
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 66	Coverage: 0.0	Temperature (°C Uterus)	From: 0.0 To: 10.0	Temperature (°C Uterus)	Temp (UTERUS): 0.0 °C
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 67	Coverage: 0.0	Temperature (°C Vagina)	From: 0.0 To: 10.0	Temperature (°C Vagina)	Temp (VAGINA): 0.0 °C
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 68	Coverage: 0.0	Temperature (°C Penis)	From: 0.0 To: 10.0	Temperature (°C Penis)	Temp (PENIS): 0.0 °C
Transmittance	From: 0.0 To: 1.0	Cloud Layer 69	Coverage: 0.0	Temperature (°C Testes)	From: 0.0 To: 10.0	Temperature (°C Testes)	Temp (TESTES): 0.0 °C
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 70	Coverage: 0.0	Temperature (°C Prostate)	From: 0.0 To: 10.0	Temperature (°C Prostate)	Temp (PROSTATE): 0.0 °C
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 71	Coverage: 0.0	Temperature (°C Seminal Vesicle)	From: 0.0 To: 10.0	Temperature (°C Seminal Vesicle)	Temp (SEMINAL VESICLE): 0.0 °C
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 72	Coverage: 0.0	Temperature (°C Ejaculatory Duct)	From: 0.0 To: 10.0	Temperature (°C Ejaculatory Duct)	Temp (EJACULATORY DUCT): 0.0 °C
Transmittance	From: 0.0 To: 1.0	Cloud Layer 73	Coverage: 0.0	Temperature (°C Urethra)	From: 0.0 To: 10.0	Temperature (°C Urethra)	Temp (URETHRA): 0.0 °C
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 74	Coverage: 0.0	Temperature (°C Vagina)	From: 0.0 To: 10.0	Temperature (°C Vagina)	Temp (VAGINA): 0.0 °C
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 75	Coverage: 0.0	Temperature (°C Penis)	From: 0.0 To: 10.0	Temperature (°C Penis)	Temp (PENIS): 0.0 °C
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 76	Coverage: 0.0	Temperature (°C Testes)	From: 0.0 To: 10.0	Temperature (°C Testes)	Temp (TESTES): 0.0 °C
Transmittance	From: 0.0 To: 1.0	Cloud Layer 77	Coverage: 0.0	Temperature (°C Prostate)	From: 0.0 To: 10.0	Temperature (°C Prostate)	Temp (PROSTATE): 0.0 °C
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 78	Coverage: 0.0	Temperature (°C Seminal Vesicle)	From: 0.0 To: 10.0	Temperature (°C Seminal Vesicle)	Temp (SEMINAL VESICLE): 0.0 °C
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 79	Coverage: 0.0	Temperature (°C Ejaculatory Duct)	From: 0.0 To: 10.0	Temperature (°C Ejaculatory Duct)	Temp (EJACULATORY DUCT): 0.0 °C
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 80	Coverage: 0.0	Temperature (°C Urethra)	From: 0.0 To: 10.0	Temperature (°C Urethra)	Temp (URETHRA): 0.0 °C
Transmittance	From: 0.0 To: 1.0	Cloud Layer 81	Coverage: 0.0	Temperature (°C Vagina)	From: 0.0 To: 10.0	Temperature (°C Vagina)	Temp (VAGINA): 0.0 °C
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 82	Coverage: 0.0	Temperature (°C Penis)	From: 0.0 To: 10.0	Temperature (°C Penis)	Temp (PENIS): 0.0 °C
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 83	Coverage: 0.0	Temperature (°C Testes)	From: 0.0 To: 10.0	Temperature (°C Testes)	Temp (TESTES): 0.0 °C
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 84	Coverage: 0.0	Temperature (°C Prostate)	From: 0.0 To: 10.0	Temperature (°C Prostate)	Temp (PROSTATE): 0.0 °C
Transmittance	From: 0.0 To: 1.0	Cloud Layer 85	Coverage: 0.0	Temperature (°C Seminal Vesicle)	From: 0.0 To: 10.0	Temperature (°C Seminal Vesicle)	Temp (SEMINAL VESICLE): 0.0 °C
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 86	Coverage: 0.0	Temperature (°C Ejaculatory Duct)	From: 0.0 To: 10.0	Temperature (°C Ejaculatory Duct)	Temp (EJACULATORY DUCT): 0.0 °C
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 87	Coverage: 0.0	Temperature (°C Urethra)	From: 0.0 To: 10.0	Temperature (°C Urethra)	Temp (URETHRA): 0.0 °C
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 88	Coverage: 0.0	Temperature (°C Vagina)	From: 0.0 To: 10.0	Temperature (°C Vagina)	Temp (VAGINA): 0.0 °C
Transmittance	From: 0.0 To: 1.0	Cloud Layer 89	Coverage: 0.0	Temperature (°C Penis)	From: 0.0 To: 10.0	Temperature (°C Penis)	Temp (PENIS): 0.0 °C
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 90	Coverage: 0.0	Temperature (°C Testes)	From: 0.0 To: 10.0	Temperature (°C Testes)	Temp (TESTES): 0.0 °C
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 91	Coverage: 0.0	Temperature (°C Prostate)	From: 0.0 To: 10.0	Temperature (°C Prostate)	Temp (PROSTATE): 0.0 °C
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 92	Coverage: 0.0	Temperature (°C Seminal Vesicle)	From: 0.0 To: 10.0	Temperature (°C Seminal Vesicle)	Temp (SEMINAL VESICLE): 0.0 °C
Transmittance	From: 0.0 To: 1.0	Cloud Layer 93	Coverage: 0.0	Temperature (°C Ejaculatory Duct)	From: 0.0 To: 10.0	Temperature (°C Ejaculatory Duct)	Temp (EJACULATORY DUCT): 0.0 °C
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 94	Coverage: 0.0	Temperature (°C Urethra)	From: 0.0 To: 10.0	Temperature (°C Urethra)	Temp (URETHRA): 0.0 °C
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 95	Coverage: 0.0	Temperature (°C Vagina)	From: 0.0 To: 10.0	Temperature (°C Vagina)	Temp (VAGINA): 0.0 °C
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 96	Coverage: 0.0	Temperature (°C Penis)	From: 0.0 To: 10.0	Temperature (°C Penis)	Temp (PENIS): 0.0 °C
Transmittance	From: 0.0 To: 1.0	Cloud Layer 97	Coverage: 0.0	Temperature (°C Testes)	From: 0.0 To: 10.0	Temperature (°C Testes)	Temp (TESTES): 0.0 °C
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 98	Coverage: 0.0	Temperature (°C Prostate)	From: 0.0 To: 10.0	Temperature (°C Prostate)	Temp (PROSTATE): 0.0 °C
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 99	Coverage: 0.0	Temperature (°C Seminal Vesicle)	From: 0.0 To: 10.0	Temperature (°C Seminal Vesicle)	Temp (SEMINAL VESICLE): 0.0 °C
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 100	Coverage: 0.0	Temperature (°C Ejaculatory Duct)	From: 0.0 To: 10.0	Temperature (°C Ejaculatory Duct)	Temp (EJACULATORY DUCT): 0.0 °C
Transmittance	From: 0.0 To: 1.0	Cloud Layer 101	Coverage: 0.0	Temperature (°C Urethra)	From: 0.0 To: 10.0	Temperature (°C Urethra)	Temp (URETHRA): 0.0 °C
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 102	Coverage: 0.0	Temperature (°C Vagina)	From: 0.0 To: 10.0	Temperature (°C Vagina)	Temp (VAGINA): 0.0 °C
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 103	Coverage: 0.0	Temperature (°C Penis)	From: 0.0 To: 10.0	Temperature (°C Penis)	Temp (PENIS): 0.0 °C
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 104	Coverage: 0.0	Temperature (°C Testes)	From: 0.0 To: 10.0	Temperature (°C Testes)	Temp (TESTES): 0.0 °C
Transmittance	From: 0.0 To: 1.0	Cloud Layer 105	Coverage: 0.0	Temperature (°C Prostate)	From: 0.0 To: 10.0	Temperature (°C Prostate)	Temp (PROSTATE): 0.0 °C
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 106	Coverage: 0.0	Temperature (°C Seminal Vesicle)	From: 0.0 To: 10.0	Temperature (°C Seminal Vesicle)	Temp (SEMINAL VESICLE): 0.0 °C
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 107	Coverage: 0.0	Temperature (°C Ejaculatory Duct)	From: 0.0 To: 10.0	Temperature (°C Ejaculatory Duct)	Temp (EJACULATORY DUCT): 0.0 °C
Base (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 108	Coverage: 0.0	Temperature (°C Urethra)	From: 0.0 To: 10.0	Temperature (°C Urethra)	Temp (URETHRA): 0.0 °C
Transmittance	From: 0.0 To: 1.0	Cloud Layer 109	Coverage: 0.0	Temperature (°C Vagina)	From: 0.0 To: 10.0	Temperature (°C Vagina)	Temp (VAGINA): 0.0 °C
Visibility (km)	From: 0.1 To: 10.0	Cloud Layer 110	Coverage: 0.0	Temperature (°C Penis)	From: 0.0 To: 10.0	Temperature (°C Penis)	Temp (PENIS): 0.0 °C
Top (ft HSL)	From: 0.0 To: 10.0	Cloud Layer 111	Coverage: 0.0	Temperature (°C Testes)	From: 0.0 To: 10.0	Temperature (°C Testes)	Temp (TESTES): 0.0 °C
Base (ft HSL)	From: 0.0 To: 10.						

## METAR PAGE

**NOTE:** The METAR real-time down load feature is only available with GenView visual scenery. It is currently not available with the Lockheed Martin P3D visual scenery.



The METAR Page is used to download real-time weather reports from METAR reporting stations for use in ELITE GenView. When METAR weather is “engaged” (activated) to function in ELITE, the weather dynamically changes when flying between METAR reporting stations and METAR time.



## MODIFICATION PAGE


The **MODIFICATION** Page is used to add, delete or modify up to fifty navaid or facility modifications or additions for each navigation data base area. For example, the US is divided into 9 areas. x 50 = 540 modifications to the navigation database.



**NOTE:** Modifications to navigation data will not be reflected in the GenView visual scenery. Variation updates may change P3D visual scenery alignments.

**NOTE:** If modifications (new creations or existing facilities) are not in compliance with FAA 14 CFR, time can not be used toward instrument credit.

## MAP PAGE



The MAP Page is a graphical representation of the flying area showing navigation facilities, frequencies, lat/long, runways, boundaries and much more. An aircraft symbol shows the flight path in real time (both horizontal and vertical profile views) that can be replayed, saved and printed for evaluation. Over 15 map features can be displayed at 8 separate zoom levels. The aircraft flight parameters (magnetic heading, altitude and IAS) can be set from the map page. In addition, you can also save and load training states or load Instrument Approach Scenarios (IAS).

# CONTROL PAGE

Visual Control	Visual Detail	Aircraft	Load / Fuel	IAS
Time of Day UTC: 18:23 18:56 LMT Day Dawn Night Dusk Date: Day 22 Month 05 Preset Level of Detail LOW MEDIUM HIGH	Light System: Basic Detailed Airport Lights: ON Approach Light System: ON Runway Lights: ON Touch Down Light System: ON Centerline Lights: ON VASI/PAPI: ON REIL / EFAS: ON Objects: Minor Roads: ON Major Roads: ON Railroads: ON Rivers: ON Taxiways: ON	mag HDG: 035 ° true ALT: 1920 ft MSL IAS: 74 kts Registration No.: HB-ICAG Set Engines on at startup: ON Yaw Control: Disabled	Empty: 3215 lbs Load: 353 lbs Main Fuel: L: 36.7 US Gal= 220 lbs R: 36.7 US Gal= 220 lbs Aux Fuel: L: -- US Gal= -- lbs R: -- US Gal= -- lbs Total weight: 4008 lbs Gross weight: 4407 lbs Fuel imbalance: Affecting CG: Disabled	IAS Scenario: LOAD Aircraft State: State: SAVE LOAD Facilities: ADF Fluctuation: +/- Reset: Reset Battery: Reset

The CONTROL Page allows you to set date and time of day, airport lighting features and runway markings. Activate yaw control (for using rudder pedals), adjust fuel loading and aircraft weight configuration and call sign. Save and load training situations you created (training states) or load optional Instrument Approach Scenarios (IAS).

## INSTRUMENT PAGE



## FREEZE


The FREEZE selection suspends the simulation. Aircraft parameters (i.e. power settings, frequency changes, OBS selections, etc.) can still be changed and the Hobbs meter continues to run. When first entering ELITE, the program is in the **FREEZE** mode as indicated by a red MENU triangle in the lower right corner of the screen. When FREEZE mode is released, the aircraft engine(s) will be in the state defined by the aircraft switches and throttles.

## QUIT

Selecting **QUIT** ends the program and returns you to the IOS (Host Computer) operating system.

# PROGRAM FEATURES

## MAP PAGE



***“HELP Tips” are available anytime by pressing ALT-H. Move the help cursor (?) over any on-screen item that you would like more information about. When the help cursor reveals its document icon, help is available for that item. Simply click on the item to display related help tips.***

The MAP page is ELITE’s command center. Its use is primarily to setup the aircraft’s initial position for a given flight or procedure, monitor the flight path and to review the flight once you have finished flying. The MAP page allows the instructor to monitor the progress of a flight in real time. Similar in appearance to an IFR Low En route chart, and laid out in approach plate-like format, the MAP page is familiar and easy to navigate. The main part of the MAP page displays the active (loaded) navigation region(s) and corresponding facility elements in plan (bird’s-eye) view.

Airports, runways, VORs, NDBs, airways, fixes, markers, DMEs,



localizers, glide slopes, Flight Information Region (FIR) boundaries, country borders, comments and communication frequencies are all graphically and/or textually represented. Pressing the Profile button brings up a profile view (similar to the profile view on an approach plate). Other knobs, buttons, and data windows located around the periphery of the main map display are used to control the following items, discussed in detail later in this section.

- Aircraft HEADING
- Aircraft ALTITUDE
- Aircraft AIRSPEED
- Flight path CLEAR
- MAP Page PRINT
- Flight PATH save/load
- ROUTE save/load
- RADIAL (compass rose) display
- PROFILE view display
- Flight path REPLAY
- Aircraft REPOsition
- DATABASE (Nav region) load
- IAS (Instrument Approach Scenario) load
- AIRCRAFT STATE save/load
- REPLAY settings
- FACILITY display
- ZOOM

## POSITION

The red aircraft symbol shows the actual aircraft position and heading. Geographical coordinates of the current view area appear in green and are located on the left side and bottom of the map for reference.



N47-20

E008-30

## MAP SCALE

The actual scale of the Map is indicated on the top right of the screen. The scale appears in green.



The scale indication changes according the actual MAP view level, which can be changed with the ZOOM function.



## NAV DATA SYMBOLS

The following Nav Data Symbols are visible on the Map page.



NDB (with identification)



DME (with identification)



ADF (with identification)



VOR (with identification)



FIX (with identification marker)



Holding pattern with direction arrow



Glide Slope indicator / Glide Path Track



Marker beacon location



Mouse cursor



ZOOM in



ZOOM out



ZOOM Limit (enlarging or reducing)



Head/Distance (Shift key)  
Add point (route planner)



Route planner (add or remove waypoint)



Change/Move point (route planner)



Active runway



Localizer transmitter (yellow)



Glideslope transmitter (red)



Runway with displacement



Airport symbol



Communication frequencies

**NOTE:** Click on this box




**for other shortcuts!**

## MAP CURSORS

The cursor changes for different functions on the MAP page:  
Normal cursor (fingertip); Zoom in cursor (Alt Key) Zoom out cursor (Shift-Alt) Zoom limit (either enlarging or reducing); Head-ing/Distance (Shift key); Add point (Route planner) (Control key).

## MAP INFORMATION

All elements displayed on the MAP page contain information applicable to that specific element such as variation, frequency, runway length, width, lighting, etc. To access information regarding a specific MAP element, **click and hold on it with the mouse**. For runway information, click on the runway's threshold.



In the example above, several facilities nearly occupy the same location or are co-located. Information on these facilities is layered. Clicking the same spot repeatedly cycles through these layers to reveal information about each specific facility. The MAP Page is a virtual facility directory. Just point, click and hold!

## MAP BORDERS

Border types:

- Flight Information Region (FIR) borders appear in brown.
- Country borders appear in green.
- Waterways and lake boundaries appear in blue.
- States appear in gray.



## REPOSITION

To easily reposition the aircraft to a specific ai port and run way, click on the **REPOS** button located toward the bottom-right of the MAP page. A list of every airport in all currently loaded NAV data-bases will be listed alphabetically by ICAO airport location identifier (LOCID). Click to reposition aircraft

reposition Aircraft

Choose a runway to position the aircraft at the beginning of it.

Navigation Area:

EDSI	07	N47 47.83 E008 42.83	BINNENGEN
EDSI	25	N47 48.02 E008 43.46	BINNENGEN
EDSL	07	N47 50.61 E008 33.65	BLUMBERG
EDSL	25	N47 50.79 E008 34.23	BLUMBERG
EDSN	09	N47 58.61 E008 53.81	NEUHAUSEN OB ECK
EDSN	27	N47 58.61 E008 54.82	NEUHAUSEN OB ECK
EDTD	10	N47 53.93 E008 31.32	DONAUESCHINGEN
EDTD	36	N47 58.10 E008 31.34	DONAUESCHINGEN
LSMD	11R	N47 23.99 E008 38.10	DUBENDORF
LSMD	29L	N47 23.84 E008 38.77	DUBENDORF
LSMD	11	N47 24.10 E008 38.02	DUBENDORF
LSMD	29	N47 23.72 E008 39.77	DUBENDORF
LSME	04	N47 05.01 E008 17.70	EMMEN AB
LSME	22	N47 06.08 E008 18.91	EMMEN AB
LSPF	07	N47 41.38 E008 31.42	SCHAFFHAUSEN
LSPF	25	N47 41.49 E008 31.82	SCHAFFHAUSEN
LSPH	01	N47 30.72 E008 46.24	WINTERTHUR
LSPH	19	N47 31.08 E008 46.39	WINTERTHUR
LSPN	15	N47 13.69 E008 04.60	TRIENGEN
LSPN	33	N47 13.51 E008 04.76	TRIENGEN
LSPV	08	N47 12.26 E008 51.86	WANGEN-LACHEN

Selected Airport:

Buttons: Select, Cancel, To Default, Default


Annotation: High-Light airport: double click or Select to reposition

If necessary, scroll until the desired airport identifier is visible. Select an airport and runway by clicking its identifier/ runway combination. Notice that the airport/runway lat/long is now highlighted and the airport's name is indicated just below the scrollable view flying area. The example above shows Donaueschingen (EDTD) selected. Click on SELECT to position the air craft at the threshold of the selected run way.

Cancel repositioning by clicking on CANCEL. You will return to the previous display.



## DEFAULT RUNWAY



It's first necessary to select the specific NAV database (or NAVset) where the desired default airport/runway is located. Click and hold the small black arrow on the right side of the panel next to "Nav area" to open a drop-down menu of loaded databases and NAVsets. Move the finger cursor over the desired selection and release the mouse button to select it. In the example on the previous page, we have chosen to use "MySet1" (see "Creating NAV Sets" on page 216.) Click on the airport/runway you would like to make the default, then click DEFAULT. Notice the airport identifier and runway selected (EDTD 18) now appear in the "Default Runway" box at the bottom-left. To actually go to the default runway now (or at any time in the future) simply click on TO DEFAULT. With a default airport/runway now saved, ELITE will automatically position the aircraft there on each subsequent startup (assuming the same NAV database/NAVset used to select the default airport/ runway is utilized).

### NOTE:

**You may choose one preferred (default) runway for each and every individual NAV data base or NAVset. The default runway always remains associated with the NAV data base or NAVset from where it was chosen.**

## MANUAL REPOSITION


It is also possible to reposition the aircraft manually by simply **dragging the aircraft symbol** to a new location. If the desired new location is outside the current visible MAP area, the MAP will start scrolling when the aircraft symbol is brought toward the edge of the screen using the method described above.





## MULTIPLE ILS/DESELECTION

Many airports in the US have the same ILS frequency for both ends of the runway. For example, Runway 27 and runway 9 at XYZ airport may have 109.90 as the ILS frequency. If runway 27 is used for approaches, the tower will turn off the ILS transmitter for runway 9 to prevent any false ILS indications.

In this instance, you (NOT ATC) must deactivate or deselect the unused ILS should there be an ILS frequency conflict. If you are flying the trainer in the vicinity of XYZ airport, tune the ILS and do not hear identifiers, this is due to the ELITE software not knowing which ILS on which end of the runway you want to use. Therefore you must deactivate the unused ILS with just a few clicks of the mouse.





## To Deactivate the ILS



1. Select <ALT> and <J> simultaneously.
2. The “finger” pointer will change to the “select/ deselect” icon.
3. Using your mouse place the “x” over the apex of the ILS you wish to deselect and push the left mouse button. The ILS antenna icon will change color from blue to amber.
4. The navaid databox will display showing the ILS is disabled.


## To Reactivate the ILS



1. Select <ALT> and <J> simultaneously.
2. The “finger” pointer will change to the “select/ deselect” icon
3. Using your mouse place the “x” over the apex of the ILS you wish to reactivate and push the left mouse button. The ILS antenna icon will change color from amber back to blue.
4. The navaid databox will display showing the ILS is now enabled.

## AIRCRAFT SNAPPING

Bring the aircraft symbol near any runway threshold to “snap” to it. This will instantly place the aircraft on the runway threshold (at field elevation) of the runway “snapped” to. This is especially useful for quick repositioning from any location, altitude, heading, air speed etc., to any specific airport runway. Although available at all ZOOM levels this feature is much easier to use at HIGH (close-in) ZOOM levels, where the runway layout is clearly visible.



## MAP SCROLLING


Similar to the MAP scrolling described above while dragging the aircraft symbol, it's also possible to scroll the MAP view without dragging the aircraft symbol. This is accomplished by clicking anywhere on the **MAP page** NOT occupied by a facility or MAP element, and dragging the cursor (fingertip) toward the edge of the visible display. Scroll speed is controlled by varying the distance of the cursor to the edge of the screen and is dependent on the amount of data to be moved. The four “arrow buttons” (**UP, DOWN, LEFT, RIGHT**) located at the bottom-right of the display, and the cursor keys on the key board can also be used to scroll the visible MAP view. If your scrolling takes you away from the current air craft position (i.e. to explore the surrounding area) and the air craft is no longer visible, **you can quickly locate the aircraft and re-center the MAP to it by clicking the red aircraft symbol surrounded by the four arrow buttons or pressing the “c” key on the keyboard.**

## CENTERING

CTRL Click to locate aircraft



Click AC symbol to bring aircraft to MAP center



Conversely, it is possible to move the aircraft to where you have scrolled. Hold down the CTRL (control) key on the keyboard and click the red aircraft symbol or just use the key combination (CTRL-C) by itself. The aircraft will be brought to the center of the present map view. Following aircraft repositioning, Heading, Altitude, and Airspeed can all be adjusted.

## MAP ZOOM LEVELS

Displays current ZOOM level controlled by I (in), O (out), and N (normal) keys respectively or “magnifying glass” buttons. When you first enter the MAP page, the display will be in normal zoom level, defined as the 100% view.



Click on the ZOOM IN or ZOOM OUT buttons to increase or decrease the zoom level.

## CUSTOM ZOOM LEVELS

The zoom percentage is indicated on the display relative to the 100% view level. You may zoom directly to an area of your choice (custom ZOOM) by tracing a rectangle around the perimeter of the area to be ZOOMed. Hold the ALT key then click-and-drag to create an outline around the desired area. Release the mouse button for the new ZOOMed view.



Level in addition to the preset ZOOM Levels (1, 5, 25, 50, 100, 250, 800, 1250). To store a custom ZOOM Level:

- Select the area you would like to ZOOM on by holding down the ALT key and drawing a marquee around the desired area.
- CTRL-Click in the ZOOM level window to store the custom ZOOM level created in previous step.
- To ZOOM to this stored level again simply click in the ZOOM Level display window.

This custom ZOOM Level can be changed anytime by simply following the procedure above to over write with a new value.

**NOTE: ZOOM level cannot be increased beyond 1250% maximum. With ZOOM level at maximum you will NOT be able to marquee a selection area to ZOOM in further.**

Marquee selection and ZOOM IN are disabled when maximum ZOOM level is reached. The ZOOM function is screen centered, NOT aircraft centered. If the aircraft is not in the center of the MAP page and you ZOOM IN, the aircraft may be temporarily “lost.” To “find” the aircraft and re-center the MAP page to it, click on the red aircraft symbol located near the bottom-right of the display.

## SHOW FACILITIES



Click on the **SHOW** button for the “Show Facilities” dialog box. Specific map details are displayed dependent upon ZOOM level. At high ZOOM levels for example, markers are visible and runways labeled with their **FACILITIES** magnetic direction. At lower ZOOM levels, certain map elements (facilities) are not displayed to prevent clutter and maintain map readability.

**NOTE:** You may determine which MAP elements (facilities) are displayed for corresponding ZOOM levels.

SHOW FACILITIES								
	ZOOM LEVEL IN %							
	1	5	25	50	100	250	800	1250
VOR	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
DME	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
NDB	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
MARKER	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
FIX	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
TRACK	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
AIRPORT	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
RUNWAY	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
LOC/GS	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
COMMUNICATION	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
HOLDING	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
V-AIRWAYS	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
V-AIRWAY IDS	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
J-AIRWAYS	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
J-AIRWAY IDS	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
COUNTRY BORDER	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
EXT. COUNTRY BRD	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
WATER	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
COMMENTS	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
METAR	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

MISC			
TRANSPONDER ID	<input checked="" type="button" value="SHOW"/>	Aircraft Info	<input checked="" type="button" value="SHOW"/>
<input type="button" value="STANDARD"/>		<input type="button" value="CANCEL"/> <input type="button" value="OK"/>	

Click on the appropriate buttons to activate or deactivate the information to be shown in each ZOOM level. Yellow buttons indicate an active button.

- Click OK and your selections will take effect.
- Click CANCEL to return to the Map with no changes.
- Click STANDARD for a preset of active facilities.

## TRANSPONDER TAG

The tag itself will appear dark-gray in color when the transponder switch is in the OFF or STBY (standby) position. With the switch in the ON position the tag will turn green (after sufficient time has elapsed for warm up). The tag will turn red when the IDENT button has been pressed.

  
4137  
253

In addition to the standard MAP elements (NAV facilities, air ports, land borders, etc.) ELITE has the ability to display an information data block (transponder tag) that moves with the aircraft symbol. This tag is similar in appearance and function to one that might be found on an ATC radar scope.


To enable this feature click on the **TRANSPONDER ID SHOW** button (it should turn yellow) located at the bottom of the SHOW FACILITIES dialog box. Although this tag will be visible any time the MAP Page is called up, users with an instructor's station (multi-monitor system) can observe it updating in real time as would an air traffic controller. Instructors can use this feature to aid in monitoring a student's flight progress by verifying the correct transponder code, heading, and altitude assignments.

The data block consists of two lines with a total of three fields. The upper line is the 4-digit transponder squawk code. The lower line displays the aircraft magnetic heading and indicated altitude fields respectively. Note that the altitude will NOT appear unless the transponder switch is in the ALT (Mode-C) position.

## MAP PAGE “SPOT WEATHER” FEATURE

The spot weather feature allows you to view the current WX conditions that exist at the aircraft's present position. The spot weather feature is especially handy when an instructor's station is being used as it allows the “instructor” to quickly ascertain the WX at any given moment without having to change screens and thus maintain uninterrupted monitoring of the student's flight. Outside air temperature (OAT), visibility, pressure, and wind will be displayed in a format similar to the “station model” symbology found on Surface Analysis charts.





Please note that the reported pressure is the actual ambient pressure (not altimeter setting) at the aircraft's current altitude. Wind speed and direction are displayed graphically using a barb and flag system (see figure on page 105) connected to a "pole" that points in the direction FROM which the wind is blowing relative to True North. In the following example, the aircraft is at 3500 feet, wind is from the southeast at 15 knots, OAT is 47° Fahrenheit, ambient pressure is 26.34 inches, and visibility is 25 statute miles. Note that unlike the station model used on Surface Analysis charts, no sky cover information is provided.

To turn ON/OFF aircraft spot weather simply click the FACILITY "show" button at the bottom of the MAP Page. On the "Show Facilities" dialog box click on the Aircraft Info "SHOW" button. This button is an ON/OFF toggle that will turn yellow when pushed in (ON). The spot weather data appears at the upper-left corner of the MAP Page at the top of the shaded information display region.

## NAVIGATION DATABASES

All airports, airport lighting, fixes, NDBs, VORs, localizers, glide slopes, communications data etc. are contained in regional navigation data bases. This data must be loaded for use in the program.

To understand the structure of the NAV databases, press the ZOOM out ( - ) button several times until an entire continent is visible. Using North America (shown below).


For example, notice there are boxes visible across the U.S. that define the regional boundaries of each NAV database. From this same view you can also determine if a specific NAV data base (region) is loaded. Gray boxes indicate data is available but not loaded. Red boxes indicate the data within its boundary is loaded and ready for use.

***Note: Each NAV data base (region) is labeled for identification. The label (USNW) shown below is for the United States North West.***

## NAV DATA DISCLAIMER

We do our best to ensure the accuracy of the NAV data in the software. Unfortunately, inaccuracies originating from the data source are beyond our control and may be encountered at some point over time in the normal course of using the product. If you do encounter data that you feel is in error please make a note and let us know. The more information you can gather about the specifics of your experience, the better. Make note of data that is suspected missing, inaccurate, erroneous, or otherwise anomalous and notify us with the details.


There can be several sources of navigation data with the trainer: the data shown on the map screen (provided by ELITE); the GPS nav data provided by Jepp/Garmin and the visual data provided by ELITE, Lockheed Martin or other 3rd party visual provider. All data



## LOADING

### NAVIGATION DATA

Click and hold on the arrow symbol part of the label. Move the cursor to Load Database and release the mouse button. When data has successfully loaded, the gray boundary box will turn to red.




arrow symbol once again and notice that Load Database is now grayed out and no longer available for selection but you can choose to release it (to free memory) or unlock it for modification (to be covered later).

**NOTE: Multiple NAV databases (regions) can be loaded simultaneously as desired. To load multiple data bases, repeat the process described previously for each additional data base.**

## CHANGING NAVIGATION DATA

Navigation databases can also be added or changed quickly by clicking the **DATABASE LOAD** button at the bottom of the MAP page. Choose a NAV database from those listed by double-clicking on its name, OR by clicking on its name then clicking OPEN to load. Databases NOT listed, which are located in other directories/folders, may also be used by navigating the correct path to locate them.





**NOTE: The last database loaded with the Load function is kept in memory and also used at the next startup.**




## CREATING NAV SETS

Following the Open Navigation Databases window, another smaller pop-up window will appear giving you the option to choose either add or replace. To Add the selected database to those already loaded, click on ADD. To replace a currently load ed database with the selected one, click on REPLACE. Click OK to complete the operation,

As stated earlier, multiple NAV databases (regions) can be loaded simultaneously. These databases can then be saved collectively as one custom NAVset. You can save as many custom NAVsets as disk space will allow. Hold down the CTRL (Control) key on the keyboard and click on the DATABASE LOAD button to display the following window:



You now may save all currently loaded databases as a NAVset. Type in a name for the NAVset and click SAVE. In the example above, we first loaded the USNW, USSE, & USSW database regions, then saved them as one custom NAVset named “MySet1.” This NAVset will now appear with the other available data bases and NAVsets at program startup. It will also be available for loading from the Open Navigation Data bases window described earlier.



## **INSTRUMENT APPROACH SCENARIOS (IAS)**

The OPTIONAL Instrument Approach Scenarios (several add-on regions available) are scripted approach exercises own in a simulated ATC environment. Each scenario begins with the aircraft at a predetermined altitude and generally positioned 15-20 miles from the IAF (Initial Approach Fix) of the selected approach.

One sample scenario is included with each ELITE package (an ILS approach into Champaign-Urbana, Illinois). The approach plate for this demo scenario can be found in the supplements section at the back of this manual or in the ELITE “Manuals” folder on your computer.

To load an Instrument Approach Scenario simply click on the “**INSTR APPR SCENARIOS**” load button at the bottom of the MAP Page.



If necessary, open the appropriate IAS folder (EC3, SE3, etc.) for the region you would like to fly in. Select and open the desired Instrument Approach Scenario from those listed. NOTE: A description of each scenario can be viewed (before it is opened) by highlighting any scenario file name with a SINGLE MOUSE CLICK. Follow on-screen dialog box instructions to start scenario.

## IMPORTANT IAS NOTES

Make sure to load and/or verify that the appropriate Navigation Database (IASSEC3, IASSE3, etc.) is active before using the Instrument Approach Scenarios. For example, to fly a scenario in the EC3 (Illinois/Wisconsin) IAS package, make sure to load the IASEC3 database.

The autopilot is ON by default at the start of each scenario. Keep the autopilot ON briefly to let the aircraft stabilize. After the aircraft stabilizes you can continue to fly the scenario utilizing the autopilot or you can disengage the autopilot and fly the aircraft manually.

Approach plates for the Instrument Approach Scenarios can be accessed by clicking on the appropriate approach plate icon on your desktop. The plates are in Adobe Acrobat® format (.pdf) and can be printed for more convenient use.

Whenever the program requires your attention you will hear a series of alert tones. When these tones are heard, direct your attention to the information display area along the top of the screen for more information.



## STATE PANEL



The state panel makes it possible to save and load aircraft “state” files. You can think of state files as a way to take a “snapshot” of the aircraft’s state at any given moment in time.

When you save a state file the aircraft’s position, altitude, heading, airspeed, etc. are stored along with current avionics settings (frequencies, auto pilot configuration, etc.). In addition, you have the option of storing Navigation, Meteo (weather), and Malfunction data as well. The saved state file can then be loaded at any time in the future and instantly position the aircraft where it was (with the same settings) when the file was saved. **State files are very useful when you want to practice the same approach, procedure, flight, or situation repeatedly.** Individual pilots and instructors often create a library of state files, which allow them to conveniently return to a desired “lesson” without having to setup the aircraft again manually.

State files can be saved at any time. Before saving a state file make sure that the aircraft is set up just the way you want it. Once everything is to your liking be sure to name the state file something that will be meaningful now and in the future. A good naming convention is to include an airport identifier or nearby Navaid and brief description such as “ORL ILS RWY 7 Low Ceilings.”

Even if you haven’t loaded this file in a while it will be easily identified as the ILS approach into Orlando Executive’s runway 7 (with low ceilings). This is much better than “My first ILS.”

## HEADING PANEL

Click in window for reciprocal heading



Aircraft Heading can easily be changed with the **MAG HDG** panel. Magnetic heading in degrees is displayed in the window next to the heading adjust knob. To change it, click and drag on the heading adjust knob until the desired value is indicated. Notice the red aircraft symbol on the MAP page turns as heading is changed to reflect the actual indicated value. Click in the Heading window to instantly get the reciprocal of the displayed value.

## ALTITUDE PANEL

Aircraft Altitude can easily be changed with the **TRUE ALT** panel. Altitude in feet (MSL) is displayed in the window next to the altitude adjust knob. To change altitude in 10 foot increments, click-and-drag on the altitude adjust knob until the desired value is indicated.



Single-click for 500 foot increments

To change altitude in 500 foot increments, first single-click on the altitude adjust knob. The knob will push in. Click and drag on the altitude adjust knob for changes in 500 foot increments. The knob will reset in 5 seconds if there is no activity, or you can click on it a second time to reset it. Upon reset, the knob will pull out to its normal position and revert back to 10 foot increment adjustment.




## AIRSPEED PANEL



Aircraft Airspeed can easily be changed with the IAS panel. Indicated airspeed in knots is displayed in the window next to the airspeed adjust knob. To change it, **click and drag on the airspeed adjust knob** until the desired value is indicated. Airspeed changes usually require some re-trimming of the aircraft upon switching back to the instrument panel. Set air speed with attention to the particular aircraft's V-speeds. Speeds appropriate to the desired flight condition should be selected.


## PROFILE BUTTON



Clicking the **PROFILE** button brings up the MAP profile. Similar to the profile view on an instrument approach plate, the MAP profile is a side view plot of aircraft altitude and flight path over time. The PROFILE button functions as a toggle switch turning the display ON/OFF. The display also contains distance marks corresponding to the DME station selected (when applicable) and shows the nominal glide path when an ILS station is tuned in.

## PROFILE VIEW OPTIONS





The **MAP profile view** provides several options for varying display presentation. These options let you tailor the appearance of the profile display allowing for improved flight analysis. The four buttons located at the bottom-right of the MAP profile display control these options.

## GLIDE SLOPE LIMITS

The **“G” (glide slope limits) button** toggles the glide slope limits overlay ON/OFF. This overlay graphically represents the electronic glide slope signal limits of the specific approach. The “G” button and glide slope overlay only become available after the proper ILS frequency has been tuned in and the approach begun. Color coding is used to represent course deviation as follows:

Yellow lines = half-scale, Red lines = full-scale

## ALTITUDE GRID

The **“A” (altitude grid) button** toggles the altitude grid lines. These lines are used in conjunction with (and are extensions of) the altitude scale markings on the right side of the profile display.

## PROFILE SCROLL

The two arrow buttons are used to scroll the profile view left and right respectively, and operate independent of the main MAP view.

In combination with the four buttons pictured above, use the ZOOM functions (previously explained) to get more detailed MAP profile views. While LOW (distant) ZOOM levels are better for viewing the big picture, HIGH (close in) ZOOM levels are good for showing minute flight path and airspeed deviations.

Profile View Examples:

The following example profiles demonstrate several of the different view options described in the previous section. The profile was


created flying the ILS RWY 7 approach into Orlando Executive (ORL) airport. For illustration purposes, the glide slope was tracked to the non-precision Minimum Descent Altitude (MDA) and NOT to Decision



Two more pro le views of the ILS RWY 7 approach into Orlando Executive airport.

Top: Pro le view with glide slope limits overlay turned ON.

Bottom: Pro le view with altitude grid lines turned ON.






Clicking the *EXTENDED* button when the MAP PROFILE is displayed expands the profile view to include air speed plot as well as gear and apposition graphs. The **EXTENDED** button functions as a toggle switch turning the expanded display ON/OFF. You can also click the EXTENDED button first (instead of the PROFILE button) to display all four (altitude, air speed, gear, & flap) profile sections immediately.


## ACFT INFORMATION

GEAR POSITION, FLAP POSITION, AIRSPEED PLOT



While viewing the MAP profile, even more detailed aircraft information is accessible for any position along the plotted flight path. First verify ELITE is in the FREEZE mode and the replay function is not activated. Click and hold the mouse button inside the profile area to display detailed information for any position along the plotted flight path. A vertical line appears at the selected location in the profile and positions the red aircraft symbol (on the main MAP screen) to the place on the aircraft track corresponding to the selected profile location clicked on. Accompanying the red aircraft symbol is the ACFT Information box with data on location, altitude, heading, airspeed, vertical speed, gear and flap positions.


The red aircraft symbol and **ACFT Information** box are displayed as long as the mouse button is held in side the MAP profile.




**NOTE:** The “ACFT Information” box is not available during flight path replay.



## RADIAL BUTTON



The Radial feature allows you to place a compass rose around any FIX or NAV aid facility in the database. Before clicking the RADIAL button look at the BEARING TO or RADIAL and DISTANCE windows near the bottom-left of the MAP screen. They should both have dashes in them. Now click the RADIAL button then click on any FIX or NAV aid in view on the MAP. ELITE instantly draws a compass rose around the selected FIX or NAV aid. Notice at the same time that the dashes located next to BEARING TO or RADIAL and DISTANCE have been replaced by actual values. Click and drag the red aircraft symbol to different positions and watch the values change in these windows to reflect the actual BEARING TO or RADIAL (from) and DISTANCE relative to the selected FIX or NAV aid. This feature displays the exact aircraft location relative to the selected FIX or NAV aid and is helpful for quick, easy, and precise aircraft positioning. In addition, simple aircraft orientation can be demonstrated without “flying” or leaving the MAP page. To toggle BEARING TO or RADIAL indication, just click on the value displayed inside the adjacent window. The compass rose is visible around the selected (UBG) VOR.





## VIRTUAL FLIGHT DATA RECORDER

Media-style buttons control play back of the Virtual Flight Data Recorder (VFDR).

### REPLAY

As you fly, ELITE continuously records your progress with an integrated virtual flight data recorder (VFDR). All recorded flight parameters are accessed via the MAP page. Flight path and profile, gear/flap position, air speed, altitude and heading are all shown and available during the course of your flight. This same data can then be used to replay the last 60 minutes of the flight or saved as a “path” file for replay at any point in the future.

### PLAY / PAUSE BUTTON:

**CLICK to START** replay. **CLICK** again to **PAUSE** replay. Replay can begin at any point in the recorded flight path. Select a different Replay start point by moving the red aircraft symbol using the Rewind and Fast-Forward buttons.

### REWIND BUTTON

**CLICK-AND-HOLD** to move **BACKWARD** through recorded flight path. **DOUBLE-CLICK to jump to BEGINNING** of recorded flight path.

**NOTE:** *Profile and extended profile data traces will still be plotted from left-to-right even when rewinding.*

## FAST-FORWARD BUTTON

**CLICK-AND-HOLD** to move **FORWARD** through recorded flight path. **DOUBLE-CLICK** to **jump to END** of recorded flight path.

## SLOW BUTTON

**CLICK** to **SLOW** replay speed.

## STOP BUTTON

**CLICK** to **STOP** Replay.

**NOTE:** The “ACFT Information” box is not available during flight path replay.

## FLIGHT WITH INSTRUMENTS ON MAP

Cockpit instruments can be displayed on the MAP page for real time reference and/or flight path replay and review. Real time instrument display is especially useful for systems with a “remote” Instructor’s Station that is not in close proximity to the main system. Systems such as those with an enclosure often have the Instructor’s Station physically located outside of the cockpit environment entirely.

Installations with a remote Instructor’s Station are common and often purposely designed to prevent the student from “peeking” at the Instructor’s Station monitor (otherwise known as the Instant Situational Awareness Indicator). Such systems require an instructor to have to look some distance over-the-shoulder of the student if he/she wants to observe the instrument presentations. By having the instruments displayed on the MAP page this problem is eliminated. The instructor no longer has to worry about the proximity of the Instructor’s Station to the main system and can easily monitor the flight by concentrating solely on the MAP page. In addition, both student and instructor can review a recorded flight on the MAP page with an enhanced total picture having the MAP and instrument presentations displayed as the flight is replayed back.



## INSTRUMENTS REPLICATED ON MAP PAGE

The first time the REPLAY feature is used an “Initial settings for Replay functions” dialog box will appear. This box specifically relates to, and is used to define, how the instruments will be displayed on the MAP page.



You can control if/when/where/how the instruments are displayed.

Change or modify the initial replay settings as desired. These settings can be changed/modified at any point in the future by simply clicking on the “settings” button at the bottom of the MAP page under REPLAY.




## PATH BUTTON




Flight path and associated data recorded by ELITE's VFDR can also be saved in a path file. The number of path files stored is limited only by available disk space. These stored path files can be loaded at any time in the future and then displayed and/or replayed on the MAP page for analysis.

Click the **PATH** button to bring up the following box:




## SAVE BUTTON

To save the flight path just flown, click the **SAVE** button to bring up the Save Path files window. Type a name in the "File name:" box ("BCRWY25" in the example) for the flight path file then click Save to complete the operation.



## LOAD BUTTON



To load a flight path, click the **LOAD** button and select a path from the previously saved paths listed.



## CLEAR BUTTON

The CLEAR button clears the flight path from the MAP page and deletes all associated flight path data from memory.


## ROUTE BUTTON



Similar to the flight path files discussed in the preceding section, you may also save a self-created route into a Route file by using the ROUTE button. Routes are explained further on in this chapter.

## PRINT BUTTON

Clicking the PRINT button captures an image of the MAP page. Once captured, you can then print the image or save it to disk for viewing later. Set MAP ZOOM level and select PROFILE as desired to “customize” the MAP to your taste before clicking the PRINT button. To print the MAP page click PRINT and follow the print dialog boxes specific to your operating system.



## SAVE

To save the MAP page image, click SAVE and type a name for the graphic file. The graphic will be saved as a bitmap (.bmp) file.



## HEADING / DISTANCE CURSOR

E6B-style calculations can be displayed using the **TIME / SPEED / DISTANCE feature**. To display magnetic track, heading, distance and time from the red aircraft symbol, to any point in the selected NAV database:


Hold down the SHIFT key on the keyboard.

The TIME / SPEED / DISTANCE cursor appears

Click and hold anywhere on the Map page. An orange course line representing the desired track from the aircraft symbol to the selected point will appear. In addition, the TIME / SPEED / DISTANCE information box appears as shown on the next page.

The upper portion of the TIME / SPEED / DISTANCE information box contains the actual location of the aircraft and selected point (mouse position) displayed as coordinates in degrees lat/long.

The lower portion of the TIME / SPEED / DISTANCE information box contains magnetic track, aircraft heading, wind speed/direction, distance, ETA, and ground speed.




**NOTE:** Heading shown (course corrected for wind) incorporates wind correction angle (WCA). This is NOT necessarily the aircraft's current heading, but rather the heading required to maintain the desired track across the ground.

Time (ETA) shown is calculated from the aircraft position to the selected point based on groundspeed.

**NOTE:** *Change wind settings on the METEO page to see the effects of different winds on ETA, heading, and ground speed. You can also observe the effects of differing aircraft speed and/or altitude in a similar manner. Simply change values in the IAS (kts) and True ALT (ft) panels respectively to have the TIME / SPEED / DISTANCE information box figures recalculated.*

## ROUTE PLANNER

The route planner is a special tool for quick flight planning. Use the keyboard commands described on the next page to design a route.



## ADD POINT

Push the CTRL (control) key on the keyboard and the cursor changes to “add point.” Click on any location from which you will start your route and you get the first route point #1. The next click displays route point #2 and so on, until you release the CTRL key. To add a point between existing points, click on the route line itself.

## REMOVE POINT

Push the CTRL & ALT keys on the key board and the cursor changes to “delete point.” Click on any route point you want to re move from your route and it disappears while the other route points renumber.

## MOVE POINT

Push the CTRL & SHIFT keys on the key board and the cursor changes to “move point.” Click on any route point you want to move and drag it with the mouse to another location. Release the mouse button and changes take effect.

## ROUTE INFORMATION

Click and hold on individual route points to get route and leg information. Point coordinates, as well as track and distance information are displayed in an accompanying window as long as the mouse button is held down.

## SHORTCUTS

To display the Shortcuts Information window, click on the “?” button. The Short cuts window will open and display all shortcuts (key combinations that enable certain functions).

SHORTCUTS			
MAP SCREEN :			
Zoom		Route	
I	In	Control + Click	New Point
O	Out	Control + Shift + Click	Move Point
N	Normal view	Control + ALT + Click	Delete Point
ALT + Click/Drag	Zoom In	Control + 'CLEAR'	Delete all Points
ALT + Shift + Click	Zoom Out		
Scroll		HDG/Dist	
Left arrow	Left	Shift + Click	Show time, speed and distance
Right arrow	Right		
Up arrow	Up	Position	
Down arrow	Down	C	Center map to ACFT
		Control + C	Move ACFT to Map center
Custom Zoom			
Control + Click in 'Zoom level window'		Store actual zoom level	
Click in 'Zoom level window'		Set stored zoom level	
Runway			
ALT + 'A' and click on runway		Manually select active runway	
ALT + 'A' and click off runway		Deselect manually selected active runway	
Taxiway			
Click and hold on aircraft / press 'ALT' and drop on runway end		Reposition aircraft on taxiway parallel to runway	
Click and hold on aircraft / press 'Shift' and drop on runway end		Reposition aircraft on taxiway perpendicular to runway	
GENERAL :			
Visual		Control	Simulation speed
T	Look down	ALT + F Freeze	S Slower
G	Look center	ALT + Q Quit	F Faster
B	Look up	ALT + H Help	Engine sound
Shift + Left arrow	Look to left		E On/Off
Shift + Up arrow	Look to front		
Shift + Right arrow	Look to right		
Click the mouse button to continue.			



## PLACING AIRCRAFT ABEAM THE RUNWAY THRESHOLD ON PARALLEL TAXIWAY

Click-and-hold on aircraft symbol / press ALT and “drop” aircraft on runway threshold.

Placing aircraft perpendicular to runway threshold in a “hold short” position on taxiway:

Click-and-hold on aircraft symbol / press SHIFT and “drop” aircraft on runway threshold.

## MANUAL SELECTION OF “ACTIVE” RUNWAY TOGGLE

An active runway is normally selected automatically by the software based on aircraft orientation and distance from a given runway. Once the active runway has been determined, runway lights are turned ON for that runway. You can however override this automatic selection by manually selecting the active runway following the procedure below.

Press ALT-A to engage or disengage mode. Once engaged, enables you to manually select ELITE’s “active” runway by clicking on the threshold of desired runway (runway color changes to green to identify that it is active). You can change your selection as many times as you like while the manual selection mode is engaged. Manual selection mode will stay engaged until ALT-A is pressed again. Only one runway at a time can be “active.” To deselect a manually selected active runway press ALT-A (if not already in manual selection mode) and click anywhere on the MAP page NOT occupied by a runway.

## SUMMARY

1. ALT-A to engage manual selection mode
2. Click on runway threshold as desired to make “active”

3. Change runway selection as desired
4. Deselect by clicking anywhere off the selected runway
5. ALT-A to disengage manual selection mode

## AIRPORT FREQUENCY INFORMATION


COMM (communication) & NAV (navigation) frequencies for associated airports and NAV facilities are in the database. As described earlier in the chapter, the MAP page also functions as a virtual A/FD (airport/facility directory). Click the com box icon




and hold on the symbol in the center of the runway complex. A Communication box will come up displaying information and number of frequencies available at this airport.

## FREQUENCY COLUMN

While holding down the mouse button, move the cursor to the SHOW corner located at the top-right of the Communication box. All frequency information available for the airport will be displayed as shown below.



Following is some of the information that may appear in the Frequency Information display:



ACC - Area Control Center  
 ACP - Airlift Command Post  
 APP - Approach Control  
 AWO - Automatic Weather Observing Station (AWOS)  
 CLD - Clearance Delivery  
 CPT - Clearance Pre-Taxi  
 CTL - Control  
 DEP - Departure Control  
 DIR - Director (Approach Control/Radar)  
 EMR - Emergency  
 FSS - Flight Service Station  
 GND - Ground Control  
 GTE - Gate Control  
 HEL - Helicopter Frequency  
 INF - Information  
 MUL - Multicom  
 ODP - Parameters (French Radio)  
 OPS - Operations  
 RDO - Radio  
 RDR - Radar Only Frequency  
 RFS - Remote Flight Service Station (RFSS)  
 RMP - Ramp / Taxi Control  
 RSA - Airport Radar Service Area (ARSA)  
 TCA - Terminal Control Area  
 TRS - Terminal Radar Service Area (TRSA)  
 TWE - Transcribed Weather Broadcast (TWEB)  
 TWR - Air Traffic Control Tower  
 UAC - Upper Area Control Center  
 UNI - Unicom  
 VOL - VOLMET

FREQ	12GRH	CALLSIGN
APP 125.32	R N	ZURICH FINAL
APP 127.75	R Y	ZURICH TERMINAL
ARR 118.00	R Y	ZURICH
ARR 119.70	R Y	ZURICH
ARR 120.75	R Y	ZURICH
ARR 127.75	R Y	ZURICH
ATI 128.52	T N	
CPT 121.80	Y	ZURICH DELIVERY
DEP 125.95	R Y	ZURICH
DEP 127.75	R Y	ZURICH
GND 118.10	Y	ZURICH
GND 119.70	Y	ZURICH
GND 121.90	Y	ZURICH
RMP 121.75	N	ZURICH APRON
TwR 118.10	Y	ZURICH
TwR 119.70	Y	ZURICH
TwR 127.75	Y	ZURICH



## METEO (WEATHER) PAGE

The METEO (meteorological) page is used to create the weather environment in ELITE. Parameters such as visibility, ceiling, wind, turbulence, pressure and temperature can be set and changed as desired to tailor the weather to meet your specific training need.

It is advisable to practice procedures without “weather” initially so as to gain a degree of proficiency in their execution. Then progressively increase the level of difficulty by adding weather to these same procedures. One example might be to practice holding without wind at first, then add winds and turbulence as you begin feeling more comfortable. This way it is easier to visualize the big picture first (without wind) and grasp the essence of the procedure. After a while you will be shooting approaches to minimums and practicing holds in strong winds and turbulence without a problem.

The METEO Page is extremely flexible and provides an opportunity for an almost infinite amount of weather possibilities. Please feel free to experiment.

## METEO GENERAL LAYOUT

The METEO Page is rather comprehensive and might look a bit intimidating at first. Actually, it is set up quite logically and is easy to use once you understand its layout. The METEO Page is actually two separate pages; the “CLOUDS” page and the “WIND” page. Both pages are set up in the same format left-to-right with “FROM” weather, “TO” weather, and “ACTUAL” weather respectively.

The CLOUDS page is set up “top-to-bottom” as Layer 1 (top layer) CLOUD AND VISIBILITY, Layer 2 (mid layer) CLOUD AND VISIBILITY, and Layer 3 (bottom layer) CLOUD AND VISIBILITY respectively.

The WIND page is set up “top-to-bottom” as WIND (top layer), WIND (mid layer), and WIND (bottom layer), ALTIMETER setting, TEMPERATURE, and STRUCTURAL ICING respectively.

Weather for Visual

Visibility (sm)

From

----

To

----

000

000

(m)

----

Top Cloud Layer

Coverage

SKC

FEW

SCT

BKN

OVC

Between (min.)

Top (ft MSL)

From

----

To

----

000

000

Base (ft MSL)

From

15000

To

15000

000

000

Transitionzone

YES

FAST

Visibility (sm)

From

----

To

----

000

000

(m)

----

Middle Cloud Layer

Coverage

SKC

FEW

SCT

BKN

OVC

Between (min.)

Top (ft MSL)

From

----

To

----

000

000

Base (ft MSL)

From

10000

To

10000

000

000

Transitionzone

YES

FAST

Visibility (sm)

From

----

To

----

000

000

(m)

----

Bottom Cloud Layer

Coverage

SKC

FEW

SCT

BKN

OVC

Between (min.)

Top (ft MSL)

From

----

To

----

000

000

Base (ft MSL)

From

5000

To

5000

000

000

Transitionzone

YES

FAST

Visibility (sm)

From

30

To

30

000

000

(m)

50000

50000

RVR (m)

----

Precision

Non Prec

CAVOK

Actual Weather at current position

Visibility

----

sm

----

Cloud Layer 1

Coverage

SKC

Top

----

ft MSL

----

Base

----

ft MSL

----

Transitionzone

----

Visibility

----

sm

----

Cloud Layer 2

Coverage

SKC

Top

----

ft MSL

----

Base

----

ft MSL

----

Transitionzone

----

Visibility

----

sm

----

Cloud Layer 3

Coverage

SKC

Top

----

ft MSL

----

Base

----

ft MSL

----

Transitionzone

----

Visibility

----

30

sm

50000

m RVR

----

Precision

Non Prec

CAVOK

Weather for Visual

Wind 10000 ft MSL and Above

Direction (° True)

From

360

↑

↓

CV

+/-

To

360

↑

↓

000

↑

↓

000

Between (min.)

Speed (kts)

From

0

↑

↓

+/-

To

0

↑

↓

000

↑

↓

000

Turbulence

From

0

↑

↓

To

0

↑

↓

000

↑

↓

000

Wind from 5000 ft MSL to

10000

ft MSL

↓

↑

Direction (° True)

From

360

↑

↓

CV

+/-

To

360

↑

↓

000

↑

↓

000

Speed (kts)

From

0

↑

↓

+/-

To

0

↑

↓

000

↑

↓

000

Turbulence

From

0

↑

↓

To

0

↑

↓

000

↑

↓

000

Wind from Ground to

5000

ft MSL

↓

↑

Direction (° True)

From

360

↑

↓

CV

+/-

To

360

↑

↓

000

↑

↓

000

Speed (kts)

From

0

↑

↓

+/-

To

0

↑

↓

000

↑

↓

000

Turbulence

From

0

↑

↓

To

0

↑

↓

000

↑

↓

000

QNH (hPa)

From

10.13

↑

↓

To

10.13

↑

↓

000

↑

↓

000

("Hg)

29.92

↑

↓

("Hg)

29.92

↑

↓

QNH Mode

Simple

Advanced

QNH Reference Altitude

----

ft MSL

↑

↓

Temperature (°C ISA)

From

+0

↑

↓

To

+0

↑

↓

000

↑

↓

000

Structural

Mode

Enforce

Enable

Intensity

Light

Moderate

Severe

000

↑

↓

000

loing

Mode

Normal

Fast

Actual Weather at current position

Wind 10000 ft MSL and Above

Wind direction (True)

360

°

Speed

0

kts

Turbulence

0

Wind from 5000 ft MSL to 10000 ft MSL

Wind direction (True)

360

°

Speed

0

kts

Turbulence

0

Wind from Ground to 5000 ft MSL

Wind direction (True)

360

°

Speed

0

kts

Turbulence

0

QNH (hPa)

10.13

hPa

("Hg)

29.92

"Hg

QNH Mode

Simple

Ref. Alt.

----

ft MSL

Temp. (ISA)

+0

°C = OAT

15

°C =

59

°F

Structural

Mode

-

Intensity

-

loing

Mode

-

loing factor

0

%

## METEO WIND SECTION

## DYNAMIC WEATHER

In addition to setting static (unchanging) weather conditions, the METEO page also allows you to create dynamic (changing) weather conditions. Dynamic weather is set up by first specifying a time period with in which these changes will occur by dialing in values (minutes) in each of the windows under the corresponding “Between” column. This is the dynamic weather time interval and determines both when and over what period of time the weather conditions will change. Next, define the conditions that will exist at the beginning (the “From” weather) and end (the “To” weather) of the specified period of time. To set the initial “From” weather simply click on the appropriate UP and DOWN arrow buttons to adjust the value of the desired weather parameter(s). Repeat this in the same way to set the “To” parameters. It is important to remember that the intensity or rate-of-change of the weather is also controlled by the procedure described in the previous section. For example, large parameter variances in relatively short time intervals produce rapidly changing weather as opposed to small parameter variances over longer time intervals.

**NOTE:** “From” column UP/DOWN buttons will remain grayed-out (not active) until a dynamic weather time interval is entered.

## ACTUAL WEATHER COLUMN

The “Actual” weather column at the far right of the METEO page displays the current actual weather parameter values and cannot be adjusted. Think of it as a “snap shot” of the weather conditions at the current location and time. This is especially useful if dynamic weather has been set up and you would like to see the exact current conditions change over the time period specified.

Actual Weather at current position	
Visibility	30 sm
	50000 m
Cloud Layer 1	Coverage 0VC
	Top 15000 ft MSL
	Base 15000 ft MSL
	Transitionzone YES
Visibility	20 sm
	32000 m
Cloud Layer 2	Coverage 0VC
	Top 10000 ft MSL
	Base 6050 ft MSL
	Transitionzone YES
Visibility	---- sm
	---- m
Cloud Layer 3	Coverage 8KN
	Top ---- ft MSL
	Base 1000 ft MSL
	Transitionzone NO
Visibility	20 sm
	32000 m
	---- m RVR

In addition, this column can be referenced when Active METAR data is engaged, as it will reflect weather changes over time and location. As both dynamic and static weather are reflected, it is easy to get a quick picture of the weather with just a glance.

## STATIC WEATHER

To set static (unchanging) weather use the “To” weather column ONLY and do NOT set in a time interval. If a time interval is set then the “From” weather automatically becomes the current weather.

**Static Weather**

Parameter	From	To	Between (min.)
Top (ft MSL)	From 5000	To 30	000
Base (ft MSL)	From 1000	To 50000	000
Transitionzone	YES	FAST	
Visibility (sm)	From 30	To 20	000
(m)	50000	32000	000
Middle Cloud Layer	Coverage SKC FEY	SCT BKN OVC	Between (min.)
Top (ft MSL)	From 10000	To 10000	000
Base (ft MSL)	From 6050	To 7500	009
Transitionzone	YES	FAST	
Visibility (sm)	From ---	To ---	000
(m)	---	---	000
Bottom Cloud Layer	Coverage SKC FEY	SCT BKN OVC	Between (min.)
Top (ft MSL)	From ---	To ---	000
Base (ft MSL)	From 1000	To 1500	0 10
Transitionzone	YES	FAST	
Visibility (sm)	From 20	To 5/8	005
(m)	32000	933	0 15
RVR (m)	---	1400	

Precision Non Prec CAVOK

**NOTE:** Remember, it is possible to use any combination of static and dynamic weather settings.

## WIND

Wind from Ground to **4300** ft MSL

Direction (° True) From **330** CCW +/- To **010** **004** **015**

Speed (kts) From **0** +/- To **0** **000** **000**

Turbulence From **0** To **0** **000** **000**

There are three wind layers in the ELITE weather environment. Each wind layer can have its own characteristics and are all configured in the same way on the METEO page utilizing identical control panels. Wind layers can NOT be less than 200 feet thick. The thickness of each layer is defined by the values entered on the panels. Note that the top of the bottom wind layer is also the base of the mid wind layer. The top of the mid wind layer is also the base of the top wind layer.

## TRANSITION ZONES

Transition Zones are available for each of the three Cloud Layers and can only be selected when overcast (OVC) coverage is in use. A Transition Zone creates a gradual visual transition to and from the cloud conditions existing above or below the layer where it is used and is noticeable only when climbing or descending into, or out of, the overcast layer it is associated with.

Weather for Visual										Actual
Visibility (sm)		From			To					Visibility
(m)										
Top Cloud Layer										Cloud Layer
Coverage		SKC		FEW	SCT	BKN	OVC	Between (min.)		
Top (ft MSL)		From			To					
Base (ft MSL)		From	15000		To	15000				
Transitionzone		YES		FAST						
Visibility (sm)		From			To					Visibility
(m)										
Middle Cloud Layer										Cloud Layer
Coverage		SKC		FEW	SCT	BKN	OVC	Between (min.)		
Top (ft MSL)		From			To					
Base (ft MSL)		From	10000		To	10000				
Transitionzone		YES		FAST						
Visibility (sm)		From			To					Visibility
(m)										
Bottom Cloud Layer										Cloud Layer
Coverage		SKC		FEW	SCT	BKN	OVC	Between (min.)		
Top (ft MSL)		From			To					
Base (ft MSL)		From	5000		To	5000				
Transitionzone		YES		FAST						
Visibility (sm)		From	30		To	30				Visibility
(m)		50000		50000						
RVR (m)										
Precision		Non Prec		CAVOK		Precision		Non Prec		CAVOK

## STANDARD VIEW

There are two inherent “transition zones” each 100 feet thick between the top/mid layers and the mid/bottom layers respectively. These transition zones comprise the last 50 feet of each layer (the lowest part of the higher layer and the highest part of the lower layer). Depending on the parameters set in each of the wind layers you may experience some turbulence and changing conditions when transitioning through these shear zones.

## WIND DIRECTION

Wind direction is always MAGNETIC and can be set in 10° increments by clicking the UP and DOWN arrow buttons. To make the wind direction variable (with respect to the selected direction) simply press the +/- button. When setting up dynamic (changing) winds it is possible to have the winds change in a clock wise or counter clock wise manner. The CW (clockwise) button is a toggle switch that when depressed will change to CCW (counter clock wise). Simply leave this button up (unselected) for clockwise rotation of the changing winds or down (selected) for counter clockwise rotation.



Wind direction is always MAGNETIC and can be set in 10° increments by clicking the UP and DOWN arrow buttons. To make the wind direction variable (with respect to the selected direction) simply press the +/- button. When setting up dynamic (changing) winds it is possible to have the winds change in a clock wise or counter clock wise manner. The CW (clockwise) button is a toggle switch that when depressed will change to CCW (counter clock wise). Simply leave this button up (unselected) for clockwise rotation of the changing winds or down (selected) for counter clockwise rotation.



## WIND SPEED

Wind speed in knots (0-60) is set by clicking the UP and DOWN arrow buttons. To make the wind speed variable simply press the +/- button.

## TURBULENCE

Turbulence level 1(light) through 12(extreme) is set by clicking the UP and DOWN arrow buttons. Separate turbulence levels can be set for each of the three corresponding wind layers.

Direction (° True)	From	360	0	CV	+/-	To	360	000	000	Wind direction (True)	360 °
Speed (kts)	From	0	0	+/-		To	0	000	000	Speed	0 kts
Turbulence	From	0	0			To	8	0.10	0.15	Turbulence	0

## CEILING (STANDARD VIEW)

Ceiling in feet Above Ground Level is set by clicking the UP and DOWN arrow buttons. To make the ceiling variable (with respect to the selected height) simply press the +/-button.

Weather for Visual										Actual Weather at current position									
Visibility (sm)					From					To					000				
(m)																			
Top Cloud Layer										Cloud Layer 1									
Coverage					SKC					Coverage					SKC				
Top (ft MSL)					From					To					Top				
Base (ft MSL)					From					To					Base				
Transitionzone					YES					FAST					Transitionzone				
Visibility (sm)					From					To					000				
(m)																			
Middle Cloud Layer										Cloud Layer 2									
Coverage					SKC					Coverage					SKC				
Top (ft MSL)					From					To					Top				
Base (ft MSL)					From					To					Base				
Transitionzone					YES					FAST					Transitionzone				
Visibility (sm)					From					To					000				
(m)																			
Bottom Cloud Layer										Cloud Layer 3									
Coverage					SKC					Coverage					SKC				
Top (ft MSL)					From					To					Top				
Base (ft MSL)					From					To					Base				
Transitionzone					YES					FAST					Transitionzone				
Visibility (sm)					From					To					000				
(m)																			
RVR (m)					From					To					RVR				
Prestion Non Prestion CAVOK										Prestion Non Prestion CAVOK									



## VISIBILITY

### Above Cloud Layer 1:

Select visibility using UP/DOWN arrows as desired.

***NOTE: Visibility can only be adjusted if cloud layer 1 coverage is set to OVERCAST.***

With an OVERCAST layer programmed, selected visibility will become the controlling visibility above the TOP of the OVERCAST up to FL400 (40,000ft). If no layer 1 OVERCAST is programmed, visibility adjustment is disabled and the visibility setting associated with next lowest OVERCAST layer will control visibility. If no lower OVERCAST layer is programmed, then “surface” visibility will be the controlling visibility for all altitudes from the surface up to FL400 (40,000ft).

### Cloud Layers 2 and 3:

Select visibility using UP/DOWN arrows as desired.

***NOTE: Visibility can only be adjusted if cloud coverage is set to OVERCAST.***

With an OVERCAST layer programmed, selected visibility will become the controlling visibility above the TOP of the OVERCAST up to the next highest OVERCAST layer programmed. This then becomes the visibility between the OVERCAST layers. If no higher OVERCAST layer is programmed, then the selected visibility will become the controlling visibility for all altitudes from the TOP of the OVERCAST up to FL400 (40,000ft).

If no OVERCAST is programmed at the current layer, visibility adjustment is disabled and the visibility setting associated with the next lowest OVERCAST layer will control visibility. sired. Preset buttons have the following corresponding visibility values:

If no lower OVERCAST layer is programmed, then “surface” visibility will be the controlling visibility for all altitudes from the surface up to the next highest OVERCAST layer programmed. If no higher OVERCAST layer is programmed, this will be the controlling visibility for all altitudes from the surface up to FL400 (40,000ft).

Surface:

Select visibility using UP/DOWN arrows or preset buttons as desired.

Precision = 1/2 statute mile

Non Precision = 1 statute mile

CAVOK (Ceiling/Visibility OK) = 30 statute miles

***NOTE: CAVOK by definition also indicates (in part) that no clouds or precipitation exist below 5,000ft. Pressing the CAVOK button in ELITE with Cloud Layer 3 Base set to <= (less than or equal to) 5100ft MSL will also set cloud coverage to Sky Clear (SKC) in addition to changing visibility to 30 statute miles.***

Preset buttons can be used to “jump” quickly to 1/2, 1, and 30 statute mile values respectively and then further adjusted as desired.

Visibility value selected will become the visibility from the surface up to the next highest OVERCAST (OVC) cloud layer programmed. If no OVERCAST layer is programmed, this will be the controlling visibility for all altitudes from the surface up to FL400 (40,000ft).

## CLOUDS

The CLOUDS Page has three Cloud/Visibility layers. Layer 1 (top), Layer 2 (mid), and Layer 3 (bottom) respectively. Select cloud coverage for each layer as desired by pressing any one of the buttons corresponding to the following :

SKC Sky Clear FEW 1/8 cloud coverage SCT 2/8 to 4/8 cloud coverage

BKN 5/8 to 7/8 cloud coverage

OVC 8/8 cloud coverage

Cloud bases can also be defined by pressing the corresponding UP/DOWN buttons. Tops can only be specified for an overcast (OVC) layer.

## VISIBILITY (STANDARD VIEW)

From	To	Selected
3/4 sm	5 sm	3/4 sm
1200 m	8000 m	1200 m
1800 m RVR	---	1800 m RVR

Visibility in Statute Miles and/or Meters can be set by clicking the appropriate UP and DOWN arrow buttons. In addition, there are three combination visibility/ceiling presets that allow you to quickly choose Precision, Non-Precision, or CAVOK minimums respectively. Once selected, these preset values can then be further adjusted as necessary. These preset minimums are as follows:

**Precision:**

200ft. (ceiling), 1/2 Mile (visibility)

To
1/2 mile
800 feet

**Non-Precision:** 500ft. (ceiling),

1 Mile (visibility)

To
1 mile
1600 feet

**CAVOK:**

5000ft. (ceiling), 5 Miles (visibility)

To
5000 feet
5 miles

## ALTIMETER

Altimeter setting in hectoPascals (same as millibars) and/ or inches of mercury can be set by clicking the appropriate UP and DOWN arrow buttons.



**NOTE:** By creating a dynamic (changing) pressure over time scenario it is easy to demonstrate the “Going from a HIGH to a LOW lookout below” adage. This is great for instructors who want to make sure their students always perform a thorough approach briefing (checking the ATIS etc.). Simply set your “To” Altimeter value lower than your “From” Altimeter value, then set in a time interval for the pressure change to take place. As the pressure drops, the student will have to descend to maintain indicated altitude. If the student doesn’t ask you for the local altimeter setting or tune in the ATIS, he/she will get a big surprise on the approach.

## TEMPERATURE



Temperature in degrees Celsius can be adjusted by clicking the UP and DOWN arrow buttons. Note that this is NOT setting the temperature directly but is actually adding to or subtracting from the ISA (International Standard Atmosphere) values. If your performance tables call for an ISA + or - (X°) day simply dial in X° to increase or decrease the OAT temperature by X° amount.

At the lower-left of the METEO Page you will find a grouping of functions that are applicable to the entire METEO Page as opposed to the control of individual weather parameters described previously. These functions are described in further detail starting with the section on “Saving and Loading METEO Files.”



## STRUCTURAL ICING


All instrument pilots are familiar with the dangers of icing and the coincident degradation of aircraft performance associated with the accretion of ice on an aircraft. Various insidious aspects of icing can creep into an otherwise “normal” flight and make for a really bad day. Increased weight, alteration of airfoil shape and disruption of air flow to name just a few, can often yield unpredictable flight characteristics at best. At worst, these elements can conspire to become catastrophic.

Like most things in life, preparation is probably the most important part of success. Aviation is no different. Proper training, pre-flight planning (you did check the icing forecasts and PIREPs right?) and overall forethought are your best course for a successful, non-eventful trip. Preparation also refers to the act of being prepared for something that may occur during a flight. This is where “staying ahead of the airplane” comes in. As Rod Machado says, “the two most important things in aviation are the next two.” If conditions are ripe for icing then be on alert for subtle performance changes and/or indications that may be symptomatic of icing.

The goal of any simulation is to sharpen your “situational” awareness. This is not only geographic (positional) awareness but “how are things going” awareness. ELITE’s intent is not to prepare you for how to exactly react to an icing “encounter” (that is best learned from the POH, aircraft manufacturer, & experience) but rather to enhance your ability to recognize that “something is not quite right” feeling and thus get you thinking. Your ability to properly analyze and successfully resolve a problem is greatly improved by quick recognition in the first place. Time and altitude are precious. In other words, don’t be caught cruising along “fat, dumb, and happy.” With a good scan, and knowledge of what indications should be normal/abnormal, the degradation of aircraft performance associated with icing should be readily apparent. Always stay ahead of the airplane and maintain a constant self-dialogue. If you notice an abnormality or something doesn’t feel quite right then try and maintain focus.



Icing can be implemented in two different ways.



1 Press “Enforce” and choose an intensity level (Light, Moderate, Severe) to activate icing regardless of OAT or visible moisture present. This can be used by an instructor for example to demonstrate the effects of icing on aircraft performance at any time.

2 Press “Enable” and choose an intensity level (Light, Moderate, Severe) to activate temperature/moisture dependent icing. Ice will begin forming at the intensity chosen anytime the aircraft is in visible moisture and at a temperature of approximately 32 degrees Fahrenheit and lower. For the purposes of the simulation, visible moisture is defined as 1/4 statute mile visibility and less, or flying in an overcast (OVC) layer.

With either icing implementation, intensity levels affect “icing factor” in the following ways:



Light: icing factor goes up to 50% in 60 minutes Moderate: icing factor goes up to 100% in 20 minutes Severe: icing factor goes up to 100% in 10 minutes Icing factor is defined as a decrease in lift, an increase in drag, and an increase in weight.

Icing factor: 100% = 50% less lift / 40% more drag / 20% more weight

Notice that Pitot tube icing is NOT part of the icing factor equation. Pitot tube icing is actually controlled separately on the MALFUNCTIONS Page. This separation of control is intentional. Although Pitot tube icing is often coincident with structural icing, structural icing can be subtler to reveal itself (initially). In most instances the onset of Pitot tube icing is more apparent and thus more easily recognizable. One form of Pitot tube icing is readily identified by a rather quick loss of airspeed indication. Airframe icing MAY be a bit harder to detect initially depending on accretion rate, icing type, etc.

**NOTE: Active METAR does NOT modify the chosen Icing Settings. You still have to ENABLE or ENFORCE Icing manually.**

## SAVING & LOADING METEO FILES

The SAVE and LOAD buttons next to Meteo state are extremely powerful. Let's say you have set up a weather scenario on the METEO Page. You get it just exactly the way you want it with all the parameters set, but you would also like to save this Meteo "state" for




future use. Simply click on the SAVE button to open the Save Meteo files dialog box.

Type a name in the "File name:" box then click Save to complete

the operation. To load this Meteo state (or any other) in the future, just click on the LOAD button to open the Open Meteo files dialog box. Select a Meteo state from those listed (previously saved) and click Open. This feature allows you to create an unlimited library of Meteo states that can be re called almost instantly.

The two RESET buttons provide a quick way to "zero-out" the METEO Page. The Meteo RESET returns all parameter settings to zero where applicable, sets the Ceiling/Visibility to CAVOK, and sets the Altimeter/ Temperature to standard. The Time Intervals RESET clears all the time interval settings used for dynamic weather.




The Ref. Meteo Time RESET button sets the Reference Meteo Time back to zero minutes. This is used in conjunction with the interval settings to control dynamic weather as explained next.



## REFERENCE METEO TIME

The Reference Meteo Time is simply an elapsed time counter that runs as the aircraft is flown. The dynamic weather time intervals discussed previously use this time to determine when to begin changing the weather as set up by the “From” and “To” parameters. If for example you set the bottom layer winds to increase between 005 and 015 minutes and the ceiling to lower between 010 and 020 minutes, these changes will not begin to take effect until the Reference Meteo Time reaches 005 minutes. At 005 minutes the bottom layer winds will begin increasing (and continue increasing) until 015 minutes where the “To” parameter values will have been reached. Five minutes after the bottom layer winds begin to increase (010 minutes) the ceiling begins to lower and will continue to lower until 020 minutes. Weather parameters that do NOT have a time interval set (static weather) remain constant.





**The Reference Meteo Time** can be RESET back to zero at any time in the flight. This will allow dynamic weather scenarios to be easily repeated. One important point to keep in mind is that if you have been flying a given sim session for an extended period of time, then set up some dynamic weather, make sure to either RESET the Reference Meteo Time or set time intervals in the future. If the time intervals set are before the Reference Meteo Time then the changes will never occur.


## MALFUNCTIONS PAGE

Instruments / Systems	Receivers / Gear / Flaps	Engines
<b>Airdata Computer Failures</b> Airdata Computer <input type="button" value="Arm"/> Altitude <input type="button" value="Arm"/> IAS/TAS <input type="button" value="Arm"/> Vertical Speed <input type="button" value="Arm"/>	<b>Receiver Failures</b> Immediate Timed Between (min.) NAV 1 Arm REC Arm 00 00 CDI LOC Arm 00 00 GS Arm 00 00 NAV 2 Arm REC Arm 00 00 CDI LOC Arm 00 00 GS Arm 00 00 DME Arm 00 00 ADF Arm REC Arm 00 00 Antenna Arm 00 00 XPDR Arm 00 00	<b>Engine Failures</b> Immediate Timed Between (min.) Left Engine Arm Arm 00 00 Left Engine Power Loss Arm Arm 00 00 Power 100 % Left Auxiliaries Oil Press Arm 00 00 Oil Temp Arm 00 00 Cyl Temp Arm 00 00 Right Engine Arm Arm 00 00 Right Engine Power Loss Arm Arm 00 00 Power 100 % Right Auxiliaries Oil Press Arm 00 00 Oil Temp Arm 00 00 Cyl Temp Arm 00 00
<b>AHRS Failures</b> AHRS System <input type="button" value="Arm"/> Pitch/Roll <input type="button" value="Arm"/> Pitch Offset 00 - + Roll Offset 00 - + Slip Rate <input type="button" value="Arm"/> Turn Rate <input type="button" value="Arm"/> Magnetic Heading <input type="button" value="Arm"/>	<b>Gear/Flaps Failures</b> Gear Arm 00 00 Flaps Arm 00 00 <b>Misc. Failures</b> Fuel Leaks Left Fuel Tank <input type="button" value="Arm"/> Right Fuel Tank <input type="button" value="Arm"/>	
<b>Stby. Instrument Failures</b> Freeze Gradual Stby. Attitude Indicator <input type="button" value="Arm"/> <input type="button" value="Arm"/> Pitch Offset 00 - + Roll Offset 00 - + Stby. Altitude Indicator <input type="button" value="Arm"/> <input type="button" value="Arm"/> Stby. Speed Indicator <input type="button" value="Arm"/> <input type="button" value="Arm"/>		
<b>System Failures</b> Vacuum <input type="button" value="Arm"/> 00 00 Static <input type="button" value="Arm"/> 00 00 Pitot Inlet Freeze <input type="button" value="Arm"/> 00 00 Pitot System Freeze <input type="button" value="Arm"/> 00 00		

***“HELP Tips” are available anytime by pressing ALT-H. Move the help cursor (?) over any on-screen item that you would like more information about. When the help cursor reveals its document icon help is available for that item. Simply click on the item to display related help tips.***

**NOTE:** Malfunctions will vary according to aircraft type and model

The **MALFUNCTIONS Page** is used to create failure scenarios. The ability to setup and practice realistic failures are one of the most powerful features in any simulation. Many of these failures would be impractical, impossible, or unsafe to recreate in an actual aircraft. Yet, exposure to these same situations in a simulated environment can give you invaluable experience (the airlines and military have proved this for decades).



Although the MALFUNCTIONS Page might appear complex at first glance, similar to the METEO Page it is actually quite easy to use and is one of the most comprehensive available. You have the opportunity to selectively or randomly fail individual instruments, systems, avionics, engines, gear, flaps, and much more. Elements of the MALFUNCTIONS page will be covered in greater detail in the following paragraphs, but to get started...

Setting up failures requires three simple steps:

- 1 Decide on the failure(s) that you would like to invoke.
- 2 Determine when you would like the failure(s) to occur. Failures can be set to occur immediately, at a specified time, or at some point within a defined “failure time window.”
- 3 Arm the failure(s) by pressing the associated ARM button(s).

Note that the ARM button will change to FAIL when that particular item has actually failed. Click on the FAIL button once to RESET the item to ARM. Click again to CLEAR the failure.

## INSTRUMENTS AND SYSTEMS FAILURES

Individual instruments can be failed in two different ways:

1. Freeze (instrument maintains indications)
2. Gradual (more realistic failure sequence occurring over time)

To “Freeze” an instrument, click on its associated ARM button under the “Freeze” column. To have an instrument fail gradually, click on its associated ARM button under the “Gradual” column. A gradual failure of this type is sometimes referred to as an “insidious” failure as it is not as readily apparent and thus could potentially be more dangerous.

Fixating on the Attitude Indicator and flying the aircraft to maintain “wings level” as it (the AI) slowly tumbles, is one example of the consequences of this type of failure.



AI - attitude indicator


DG - directional gyro

VSI - vertical speed indicator

ALT - altimeter


ASI - airspeed indicator

TC - turn coordinator



## FAILURE TIME WINDOW

The “Between” column is used to set the “failure time window” interval. The values entered in minutes (00-99) are compared to the Ref. Failure Time and determine when or during what time period (window) the corresponding ARMED failure will occur. If for example we want the Attitude Indicator to gradually fail at some point between seven and fifteen minutes from now, we would simply enter 07 and 15 respectively in the “Between” column and press the ARM button in the “Gradual” column next to “AI.” If this were done at the start of our flight the Ref. Failure Time would already be set to zero. But, if we had been flying for some time and wanted the failure to occur between seven and fifteen minutes from now we could just RESET the Ref. Failure Time. As the Ref. Failure Time counts up from zero as we fly, the Attitude Indicator will begin its gradual failure at some time between seven and fifteen minutes.





## IMMEDIATE FAILURE


To invoke an immediate failure, enter the SAME values (minutes) in each window that correspond to the current Ref. (reference) Failure Time displayed at the lower-left. If for example the Ref. Failure Time displayed is 07 (7 minutes), enter 07 in BOTH “Between” windows next to the desired ARMed failure. An easier way to invoke an immediate failure is to leave both “Between” values at 00 and simply RESET the Ref. Failure Time by pressing the RESET button next to the Ref. Failure Time display window. Keep in mind though that all failure time window intervals use the Ref. Failure Time and as such will be affected.

## SPECIFIC TIME FAILURE

To invoke a failure at a specific (future) time, enter the SAME values (minutes) in BOTH “Between” windows. If we had been flying for fifteen minutes and wanted the Pitot Tube to freeze over with an accumulation of ice three minutes from now, we would simply enter 18 and 18 respectively in the “Between” column. When the Ref. Failure Time reached 18 minutes, the Pitot Tube would freeze over and we would observe a subsequent erroneous indication on the Airspeed Indicator (a good time to turn ON Pitot heat).

Note that if a System failure is invoked its associated ARM button will change to FAIL when that particular System actually fails. Affected items within the failed system will be flagged for easy identification. The ARM buttons of these items will NOT change to FAIL. If for example we FAILED the Static System, the ARM button under “Static” would change to FAIL at the time of the failure and the VSI (Vertical Speed Indicator), ALT (Altimeter), and ASI (Airspeed Indicator) labels respectively would change to or change in color.


## INSTRUMENTS AND RECEIVERS



Failures in this panel are setup in much the same way as previously discussed except that immediate failures are invoked by using the ARM buttons in the “immediate” column. To set a specific failure time or a failure time window interval you must use the ARM buttons in the “Timed” column.

## ENGINE FAILURES

Failures in this panel are set up exactly the same as the previous (Instrument / Receivers) panel. Note that it is not only possible to fail an engine, but to also simulate a power loss (leaving partial power). Combine this with various “auxiliary” failures and you have the opportunity to create some interesting failure scenarios.



A good way to see if a student is including engine instruments in his/her scan is to invoke an Oil Pressure failure and see if the student notices the pressure dropping. To really bring the point home set up a scenario in which the Oil Pressure drops followed by an increase in Oil Temperature and subsequent power loss.

**NOTE:** The Power Loss window shows the power available, NOT the percentage of power loss. If for example the power loss window were set to 40%, this would indicate a 60% loss of power.

**NOTE:** Once an engine failure or power loss has been invoked, the failure must be CLEARED to allow for engine restart or power restoration.


## RANDOM FAILURES

The Random Failures panel allows you to experience what it is like to expect the unexpected. To set up a random failure simply enter the failure time window interval(s). As previously described, you can use these intervals to invoke failures immediately, at specified times, or within a defined failure time window. Then dial in the number of failures you would like to occur. If for example we entered in a failure time window of between 3 and 12 minutes, then entered 2 in the Instruments window, ELITE would randomly fail two of the six instruments (each at some random time between 3 and 12 minutes).



**NOTE:** “Engines” does NOT refer to the number of engines but rather to the number of possible engine failures. Depending on the aircraft there might be as many as 5 failure types (power loss, oil pressure, oil temperature, hot starts, hung starts, etc.) as shown on the engine failure panel.

## FAILURE “STATES”




Similar to saving and loading METEO States, the SAVE and LOAD buttons next to “Failure State” enable you to Save and Load Failure States.



You can literally develop a library of these states that can be instantly recalled for use anytime. Create a failure scenario (state) and tweak it until you are satisfied, then click the SAVE button to open the Save Malfunction files dialog box. Type a unique name in the “File name:” box such as “OilPressLoss” then click Save to complete the operation. To load this failure state (or any other) in the future, just click on the LOAD button to open the Open Malfunction files dialog box. Select a failure state from those listed (previously saved) and click Open.

### RESET TO ARM



The “Reset to ARM” and “Clear all failures” buttons provide a quick

way to RESET the MALFUNCTIONS page as required. Use the “Reset to ARM” button when a completed failure scenario sequence needs to be repeated. Pressing this button will leave the entire failure “state” intact, but RESET all FAIL buttons back to ARM (much easier than having to reset each individual Fail button).



Use the “Clear all failures” button to **RESET** the entire MALFUNCTIONS page (including failure time intervals).

## REF FAILURE TIME


The **Ref. Failure Time RESET button** sets the Reference Failure Time back to zero minutes. This is used in conjunction with the failure time window interval settings as described previously.



The MALFUNCTIONS page is extremely flexible and provides an opportunity for an almost infinite amount of failure scenario possibilities. Please feel free to experiment.

**NOTE:** different aircraft modules may show different malfunction options based on the systems of that aircraft

## CONTROL PAGE




*“HELP Tips” are available anytime by pressing ALT-H. Move the help cursor (?) over any on-screen item that you would like more information about. When the help cursor reveals its document icon help is available for that item. Simply click on the item to display related help tips.*

Use the **CONTROL** page to configure air craft load and fuel, control visual settings, load Instrument Approach Scenarios, save/load “STATE” files, and more.

## VISUAL DATE & TIME PANEL

Use the **Visual** panel to configure ELITE’s visual display settings. Everything from Time-of-Day to the amount of runway environment detail displayed can be changed.



## SET DATE AND TIME

Set the Time of Day and Date. Daylight is accurately reflected based upon navigation data loaded and time set.

At program start, ELITE references your computer's internal clock, then applies the (LT)/(UTC) offset from the General settings dialog box on the Configuration. The calculated current UTC (Universal Time Coordinated) time is then used for all cockpit clocks and appears on the Time of Day panel in the UTC window. The time displayed in the LMT (Local Mean Time) window will probably NOT reflect the current local watch time of the area flown in. THIS IS NORMAL! LMT is used to calculate accurate sun rise and sunset times. Depending on aircraft location within the specific Time Zone flown in, and Daylight Saving Time, LMT may be "off" by as much as 2 Hrs. Use this time only as a reference for setting day/night flying conditions. To change time of day, click and drag on hours/minutes adjust knobs located below LMT display window.

## PRESET LEVEL OF DETAIL (GENVIEW ONLY)

Software "performance" is directly related to the computer hardware and associated capabilities used to run it. Many factors such as processor speed, memory, video card and drivers, come together to formulate what the end user perceives as computer "power." Some performance gain may be achieved however through the software by fine-tuning Gen View's visual settings.

Based on the processing power of your computer, you may want to adjust the Level of Detail (LOD) setting by pressing one of the LOW, MEDIUM, or HIGH buttons.




These buttons control various parameters used to create the view of the outside world and determine the resulting “Level of Detail” implemented by these parameters. “Fast” computers can normally use a HIGH setting, while relatively “slower” computers may require a LOW or MEDIUM LOD setting. In addition, these same buttons can be used to select one of three Visual Detail presets.

Unlike the LOD parameter settings, which are broader in nature, the Visual Detail settings are related to specific lighting and scenery object elements. The processing power required to display these elements might cause the simulation to run sluggish on relatively slower computers. The Visual Detail panel allows you to tweak these settings to get the best performance possible from a given system.

Simply CTRL-click on any one of the LOW, MEDIUM, or HIGH buttons (turns orange) and its corresponding Visual Detail pre set will become activated. Presets can then be modified manually as desired by selectively turning ON/OFF items in the Visual Detail panel. The selected LOW, MEDIUM, or HIGH button will remain orange as long as the Visual Detail buttons corresponding to that preset match. If the Visual Detail buttons are modified after selecting a preset, the selected LOW, MEDIUM, or HIGH button will return to gray to signify the preset has been modified. Experiment to determine what configuration

yields the best combination of performance and visual detail. Day, Dawn, Night and Dusk are quick adjustments to time light levels.



## ENGINE “ON” AT STARTUP

The engine(s) start automatically at initial program startup when the ON button is active. To start engines manually (with checklist) turn off (ON button NOT lit)



## AIRCRAFT PANEL

The heading, altitude, and airspeed panels found on the MAP page are duplicated here for convenient aircraft setup while using the Control page. These panels function exactly the same as those on the MAP page discussed earlier in the chapter.



Set MSL altitude. To increment by 500 ft., click in the number window. The knob will show an orange dot. When you use the knob, increments will be by 500 ft. Click again in the window to deactivate. Feature will deactivate itself in 5 seconds if there is no activity. Set indicated airspeed (knots)

## ENABLING FUEL IMBALANCE

When ENABLED, allows for flight characteristics to be affected by lateral asymmetric fuel loading. Set aircraft load weight (change from KGs to LBS. on CONFIGURATION page, under UNITS. Overload indicator Total aircraft weight

## SETTING AIRCRAFT IDENTIFICATION

You can customize the aircraft identification “placard.” Click on the SET button in the Identification panel. Another dialog box will appear that will allow you to enter a unique registration number.



## STATE PANEL

The **STATE** panel makes it possible to save and load aircraft “state” files. You can think of state files as a way to take a “snapshot” of the aircraft’s state at any given moment in time. When you save a state file the aircraft’s position, altitude, heading, airspeed, etc. are stored along with current avionics settings (frequencies, auto pilot configuration, etc.). In addition, you have the option of storing Navigation, Meteo (weather), and Malfunction data as well. The saved state file can then be loaded at any time in the future and instantly position the aircraft where it was (with the same settings) when the file was saved. State files are very useful when you want to practice the same approach, procedure, flight, or situation repeatedly. Individual pilots and instructors often create a library of state files, which allow them to conveniently return to a desired “lesson” without having to setup the aircraft again manually.







State files can be saved at any time. Before saving a state file make sure that the aircraft is set up just the way you want it. Once everything is to your liking be sure to name the state file something that will be meaningful now and in the future. A good naming convention is to include an airport identifier or nearby Navaid and brief description such as “ORL ILS RWY 7 Low Ceilings.” Even if you haven’t loaded this file in a while it will be easily identified as the ILS approach into Orlando Executive’s runway 7 (with low ceilings). This is much better than “My first ILS.”

## SAVING STATES

To save the current aircraft state, click the **SAVE** button to bring up the **Save State file** window.




Type in a name for the “state” file and click Save. Select “state” file options as desired, then click OK.



## LOADING STATES

To load an aircraft state file, click the LOAD button to bring up the Open State files window.

Highlight the “state” file you wish to load from those listed, then **click OPEN**.



## TIME FLOWN PANEL



The Time Flown panel always indicates the elapsed time ELITE has been flown. Time automatically stops when the flight is frozen or while not flying on the Instrument panel.

## CONFIGURATION PAGE

General settings	Aircraft Information	Instrument Configuration
<b>SET</b>	<b>NEW ACFT MODULE</b>	<b>SAVE</b>
Stick : Standard	Aircraft module Archer3FullHD.pho	Resolution Archer 3 (D0), 16:9
<b>Hardware Configuration</b>	<b>AIRCRAFT DATA BELOW IS FOR INFORMATION PURPOSES ONLY. THESE VALUES ARE PART OF THE AIRCRAFT CONFIGURATION AND CANNOT BE CHANGED BY THE USER.</b>	ADF Indicators Bendix/King 227-00 ADF
Computer <b>SET</b>		Carburetor Heat No Hardware
Elite Hardware <b>SHOW</b>		Fuel selector No external selector
<b>Controls</b>	Various Aircraft Archer III FullHD (v1)	Fuel boost/Pitot switch External switch
Calibration <b>SET</b>	Engines 1 Rated power 180 HP Propeller Fixed pitch Service ceiling 14000 ft Gear Fixed Gross weight 1158 kg Empty weight 826 kg Usable fuel 48.0 US gal = 130.7 kg	CDI 2 Indicators CDI 2 without GS
Dampening	Speed Never exceed speed 154 kts Best single engine rate of climb --- kts Minimum single engine control speed --- kts Maximum structural cruising speed 125 kts Cero flaps stalling speed 50 kts Flaps extended stalling speed 45 kts Maximum speed for flaps extended 102 kts Maximum speed for gear extended --- kts Maximum speed for gear operation --- kts	
Pitch 0.00		
Roll 0.00		
Yaw 0.00		
<b>Units</b>		
Weight LBS KO		
Fuel Weight %Tot F %Fuel T LITRE US G I-M-P G		
<b>Handling</b>	<b>Sounds</b>	
Ask before QUIT YES	Intro ON Idents 100	
SAVE state files DISABLE	Engine ON 100 Flaps ON 100	
<b>Color for Digits</b>	Gear ON 100 IAS ON 100	
RED YELLOW	Cockpit ON 100	
<b>Menu Position - Startup</b>	3D Sound OFF	
Screen 2ND - 2ND		
<b>Aircraft Reposition</b>		
Rvy Offset 0 ft		

*“HELP Tips” are available anytime by pressing ALT-H. Move the help cursor (?) over any on-screen item that you would like more information about. When the help cursor reveals its document icon, help is available for that item. Simply click on the item to display related help tips.*

Use this page to configure flight controls, hardware, instrumentation, and sound. Some of these have already been covered during the Startup procedures in Chapter One.

## STATE FILES

When the “Ask for **State File** at Program Start” button is ON, ELITE will display a dialog box (on every startup) allowing you to choose any training “State File” previously saved. You will be positioned with the same aircraft in that specific state (including Nav data and Meteo State selected!).

## VISUAL SETTINGS

When the “Visual Settings always store in Preference File” button is ON, all visual settings selected on the Control page are stored. (GenView Only!)

## IOS PASSWORD PROTECTION



You may protect the Configuration and Modification pages with a password. Click on the SET button, type a password and follow remove instructions on the screen. Click OK to save the settings. To delete the password, click the SET button and enter the password. When asked for a new password, select OK with the password field blank.

## TIME DIFFERENCE LT TO UTC

For ELITE to properly calculate daylight (sunrise and sun set) times, you must set the difference between your local time (LT) and UTC (Zulu) time. First verify that your computer's clock is set correctly. Click on the SET button. Calculate your local time using 12:00UTC as a reference. For example in Orlando, Florida (UTC-5) you would set the local time value to 07:00, i.e. 12:00UTC - 5Hrs = 07:00. For periods of Day light Saving Time (UTC-4) in Orlando, this value would be set to 08:00. **To have ELITE perform this calculation automatically (recommended) simply click the “Take Local Time from Computer” SET button found in General Settings.**



## ATD DETECTION REPORT

With ATD Detection Report button ON (ATD version only), ELITE will verify (on every startup) connection and proper communication with the required hardware necessary for use as an approved ATD (Aviation Training Device). If a required device(s) is not present or proper communication cannot be established, a warning message will appear during program start advising the system may NOT be used for flying credit allowed by the FAA.

## ACTIVATING FAILURES WITH KEYBOARD

Failures Activating with Keyboard ON allows the user to fail specific instruments and systems via the keyboard completely independent of the simulation. This is especially useful for system configurations not incorporating a separate graphical instructor's station (2nd monitor). The instructor can control failures without interruption of the simulation or the student's flight. Keyboard commands are as follows:

INSTRUMENT FAILURE	ACTIVATE INSTANT FAILURE	ACTIVATE GRADUAL FAILURE	DEACTIVATE FAILURE
Attitude Indicator	1	7	Shift 1 or 7
Directional Gyro	2	8	Shift 2 or 8
Vertical Speed Indicator	3	9	Shift 3 or 9
Altimeter	4	0	Shift 4 or 0
Airspeed Indicator	5	Q	Shift 5 or Q
Turn Coordinator	6	W	Shift 6 or W

SYSTEM FAILURES	ACTIVATE INSTANT FAILURE	ACTIVATE GRADUAL FAILURE	DEACTIVATE FAILURE
Vacuum	ALT 1	N/A	Shift & ALT 1
Static	ALT 2	N/A	Shift & ALT 2
Pitot Freeze	ALT 3	N/A	Shift & ALT 3
Pitot & Drain	ALT 4	N/A	Shift & ALT 4
Electrical	ALT 5	N/A	Shift & ALT 5
Left Engine (or single)	ALT 6	N/A	Shift & ALT 6
Right Engine	ALT 7	N/A	Shift & ALT 7

## MEASUREMENT FOR WEIGHT & FUEL

You can choose what units of measurement are displayed for weight and fuel values as desired.

- Weight in pounds or kilos
- Fuel in liters, U.S. gallons or Imperial gallons



## CHANGING COLOR OF NUMBERS

For readability, you can change the color of numbers shown on all pages (except the instrument panels.) Click on RED or YELLOW as desired.





## SOUND AND VOLUME CONTROL

ELITE's advanced True Integrated Sound (ATIS) smoothly mixes multiple-channel aircraft and ATC sounds providing a realistic, uninterrupted, high quality, ((stereo)) audio environment (stereo sound card and speakers required). The Sounds control panel illustrated on previous page lets you tailor, or mix individual sound elements, giving you complete control of your ELITE sound experience.



**NOTE:** *Engine sound can also be switched ON or OFF with the “E” key on the keyboard.*

## 3D SOUND



For ELITE technicians only! The iGATE sound will be properly configured before installation. Do not change settings without consulting ELITE technical support personnel. Depending on hardware configuration, 3D sound ON allows for an enhanced audio experience on 3D compatible sound systems.

## AIRCRAFT INFORMATION

The Aircraft Information panel shows actual performance characteristics of the aircraft. Figures cannot be changed and are for information purposes only.

### Aircraft module

Archer3FullHD.pho

AIRCRAFT DATA BELOW IS FOR INFORMATION PURPOSES ONLY. THESE VALUES ARE PART OF THE AIRCRAFT CONFIGURATION AND CANNOT BE CHANGED BY THE USER.

### Various

Aircraft Archer III FullHD (v1)

Engines	1	Rated power	180 HP
Propeller	Fixed pitch	Service ceiling	14000 ft
Gear	Fixed		
Gross weight	2552 lbs	Empty weight	1822 lbs
Usable fuel	48.0 US gal = 288.1 lbs		

### Speed

Never exceed speed	154 kts
Best single engine rate of climb	--- kts
Minimum single engine control speed	--- kts
Maximum structural cruising speed	125 kts
Zero flaps stalling speed	50 kts
Flaps extended stalling speed	45 kts
Maximum speed for flaps extended	102 kts
Maximum speed for gear extended	--- kts
Maximum speed for gear operation	--- kts

## NAV DATA “MODIFICATION PAGE”




**“HELP Tips”** are available anytime by pressing ALT-H. Move the help cursor (?) over any on-screen item that you would like more information about. When the help cursor reveals its document icon help is available for that item. Simply click on the item to display related help tips.

The **Modification Page** allows you to **create or modify** up to 200 facilities, fixes, NAVaids or holding patterns in each navigation data base worldwide. This NAV DATA is inherent to ELITE software only. Only modification of variation will be reflected in the P3D visual scenery! Changes to runways and lighting will NOT!

### CREATING FACILITIES

The desired facility can be created by clicking on the appropriate button. When a button is clicked, a window will appear showing the detailed data fields required to create the facility.

Any facility can be modified by using the MODIFY button, shown on the Modify panel.



**Click on the MODIFY button** and then the desired facility to be changed. A window will appear with the specific data of the facility. Data can be changed and the change will take effect after clicking on the OK button.

## DELETING FACILITIES

Facilities can be deleted as well as created and modified. Click on the DELETE button first and then on the facility you want to delete. A pop-up window will ask for verification before the deletion takes place.

**NOTE: A deletion or modification does not modify the original data base file on your hard disk, but only a copy of the data.**

If you choose to delete a self-created facility, the pop-up window will ask you if you really want to irrevocably delete your self-created facility.


After creating, modifying or deleting a facility, click on the OK button to confirm the changes.

If you click on the CANCEL button, all previous instructions are cancelled and you return to the Modification page.

All self-created and modified facilities are displayed in red on the Modification page. When changing to the Map page, your modifications have the same appearance and color as all original data. When changing back to the MOD page, however, your changes will again appear in red.


## UNDO CHANGES

To return to the original status of facilities, you can undo modifications or deletions. Hold the **ALT** key while clicking on the **MODIFY** button. The following pop-up window will appear on the screen.



Now, select and choose to undo changes.

To restore an original facility that had been deleted, hold the **ALT** key while clicking on the **DELETE** button. The following pop-up window will appear on the screen.



You can now undo a previous facility deletion and it will once again be displayed on the Map.

Deleting an existing (original) facility counts as one change. Deleting a self-created or modified facility releases one for further use. Undeleting a previous deletion of an original facility will also release a change for further use.


When 200 modifications have been made the following message appears:




## FACILITY INFORMATION

Click and hold the mouse on any facility to display detailed information about that facility. For run way information, click on the runway threshold.

When facilities are in the same location or covered by other ones, click on the same spot once more and information about the next facility will appear.



In the example above, several facilities nearly occupy the same location or are co-located. Information on these facilities is layered. Clicking the same spot repeatedly cycles through these layers to reveal information about each specific facility





## ADDING FACILITIES



**VOR/VORTAC/TACAN**

Identification code:  **VOR**

Location: **N28 33.243** **W081 18.585**

Variation: **000.0** ° Station elevation: **1000** ft

Frequency: **108.00** MHz DME bias: **0.0** nm TCN Channel: **----**

**CANCEL** **OK**

**DME**

Identification code:

Location: **N28 33.243** **W081 18.585**

Variation: **000.0** ° Station elevation: **1000** ft

Frequency: **108.00** MHz DME bias: **0.0** nm

**CANCEL** **OK**

**NDB**

Identification code:

Location: **N28 33.243** **W08 1 18.585**

Variation: **W00.0** ° Station elevation: **1000** ft

Frequency: **350.0** KHz Range: **15** NM Night Reduction **ACTIVE**

CANCEL OK

**MARKER**

Type: **OUTER** MIDDLE INNER

AIRWAY TERMINAL

Identification code (Awy/Term):

Location: **N28 33.243** **W08 1 18.585**

Variation: **W00.0** ° Station elevation: **1000** ft

Orientation: **000** °

CANCEL OK

**FIX**

Identification code:

Location: **N28 33.243** **W08 1 18.585**

Variation: **W00.0** °

CANCEL OK

**LOC/GS**

LOC:

Identification code:  Location: **N28 33.243** **W081 18.585**

Variation: **W00.0** ° Station elevation: **1000** ft Front Crse W.: **3.0** °

Frequency: **108.00** MHz Magn. Loc. Bearing: **000** ° **BACKCOURSE**

---

GS: **GS EQUIPPED**

Location: **N28 33.243** **W081 18.585** GS Angle: **3.0** °

or HDG: **000** ° Distance: **0.0** nm

---

DME equipped: **LOC** **GS** **DISP** DME bias: **0.0** nm

**CANCEL** **OK**

**HOLDING**

Identification code:

Location: **N28 33.243** **W081 18.585**

Variation: **W00.0** ° Inbound course: **000** °

Turn direction: **LEFT** **RIGHT**

Leg length: **2.8** nm Turn radius: **1.5** nm

**CANCEL** **OK**



## EXTERNAL VISUAL DISPLAY - GENVIEW™ ONLY

### GENVIEW VISUAL DISPLAY

GenView™ is an add-on visual display database that will allow you to fly in the virtual world with accurate digital elevation models (DEM) and vector data accurately depicting rivers, lakes, highways, railroads and built up areas. In addition, every airport environment is highly rendered with runway designators, appropriate runway lighting, approach light systems and properly lighted generic taxiways. Inherent to the DEM is a fully programmable dynamic weather system that further enhances the realism of flight by providing 3-D obstructions to visibility, cloud coverages, and several transition zones or layers for IFR, MVFR, SVFR or VFR on top. Utilizing actual downloadable METAR reports, you can create a real-time flight experience and save the most challenging weather scenarios for recurrent training.

### GENVIEW VECTOR DATA

Elements in the digital elevation model depicts rivers, lakes, highways, railroads and built up areas such as cities, towns, villages, etc.

### GENVIEW RUNWAY DEFINITIONS

1. Runways will have number designators such as 08 (8 for USA) or 26.
2. Centerline lights if appropriate. Space between lights is 50m.
3. Runway edge lights if appropriate. Space between lights is 50m.

Approach lighting system. Distance is in accordance with ICAO/FAA standard.

## TAXIING IN GENVIEW

1. Generic taxiways have been implemented in GenView to allow the pilot to more closely follow the checklist sequence if used (conducting run ups, for example). Though the location of the runway and NAVAids are always accurate, the layout and orientation of taxiways may not represent the exact layout at that airfield.

2. When ELITE is first loaded, the default position of the aircraft is on the end of the run way. You can reposition the aircraft relative to the taxiway in three ways:

a. Taxi the aircraft to the position you want to start (least recommended, especially if you are in a hurry)

b. Go to the MAP Page. Click on the aircraft symbol and hold the mouse button. Press the ALT key and drop the aircraft at the runway end and it will reposition to the taxiway parallel to the active runway.

c. Go to the MAP Page. Click on the aircraft symbol and hold the mouse button. Press the SHIFT key and drop the aircraft at the runway end and it will reposition perpendicular to the active runway.

3. The length of the runway determines the width of the taxiways (longer runways equal wider taxi ways). Wide taxiways have blue edge lights spaced at every 50m/164ft. Smaller taxiways have green centerline lights spaced at 50m/164ft. Runways with a width of 16m/52ft or less have no taxi way lights.

4. The length of the runway defines the amount of taxiway exits:

Runway length smaller 2500 ft 2 exits Runway length smaller 4500 ft 3 exits Runway length smaller 6500 ft 4 exits Runway length equal or longer 6500 ft 5 exits.

## GENERAL INSTRUMENTS

### ARTIFICIAL HORIZON




### AIRSPEED INDICATOR

The airspeed indicator (ASI) is indicated in knots on the ASI instrument. The white, green and yellow arcs as well as the red line have the standard meaning. True airspeed may be calculated by applying the usual techniques assuming ISA temperature. If the air speed indication should decrease without speed reduction, the pitot may be iced. In order to prevent pitot icing, turn the PITOT HEAT to ON.



## TURN INDICATOR

The Turn Indicator (Turn coordinator) is actually a combination of two instruments. The aircraft symbol indicates rate of roll and rate of turn and is proportional to the roll rate. When the roll rate is reduced to zero, the instrument provides an indication of the rate-of-turn. The marks stand for a standard rate-of-turn ( $3^\circ$  per second). The ball reacts to gravity and centrifugal force to indicate the need for rudder application.



## ALTIMETER

The Altimeter is the conventional three-pointer type. The air pressure is indicated in inches Hg (on the right side) and millibar in hPa (on the left side). Be aware that the instrument only shows the true altitude when its pressure setting corresponds to the QNH setting in the Environment panel on the Meteo screen.



## VERTICAL SPEED INDICATOR

The Vertical Speed Indicator (VSI) indicates the rate-of-climb or rate-of-descent. Vertical Speed is not instantaneous and will exhibit trend and lag effects.





## GYRO COMPASS

The Gyro Compass (if equipped) indicates the actual heading. It has a turning compass card. The directional gyro (DG) is not slaved with the compass and will precess. As in the actual aircraft, it must be adjusted.

The orange arrow (heading bug) can be set with the rotary dial on the avionics console HDG BUG sub panel.



## HORIZONTAL SITUATION INDICATOR

The Horizontal Situation Indicator (HSI) is connected to the NAV1 receiver. It consists of a turning compass card, a yellow course pointer (CDI) turned by the left rotary dial, an orange heading bug moved by the right rotary dial and a yellow glide slope mark on both sides (when on ILS). The actual course is indicated by the white lubber line on the compass card. The HSI replaces the standard directional gyro in the aircraft's panel, combining slaved heading and VOR/LOC/Glideslope deviation information into one compact display.

**NOTE:** A red HDG or NAV flag indicates absence of station reception or malfunction of the receiver.



## VOR/LOC/GLIDESLOPE INDICATOR

The VOR/LOC/Glideslope Indicator utilizes the conventional cross pointer layout. It is connected to the NAV receivers (NAV1 or NAV2). The compass card is rotated by the OBS knob in the conventional manner.



Receiver is set to a VOR



Receiver is set to an ILS

The RADIO MAGNETIC INDICATOR (RMI) incorporates a slaved (self -rotating) compass card, a green single pointer, and a yellow double pointer. The green single pointer may be switched between NAV1 receiver and NAV2 receiver. The double-line pointer is pointing to the ADF receiver. If any navigation set is not receiving a valid signal from a station, the corresponding needle is parked in the horizontal position.



## MOVING DIAL INDICATOR

The Moving Dial Indicator (MDI) is connected to the ADF receiver. It is an improved Relative Bearing Indicator (RBI) which has a fixed 360° compass card, whereas the compass card of the MDI can be turned by the rotary dial. Bearing Pointer indicates relative or magnetic bearing to station as selected by HDG knob.



## AVIONICS

ELITE is equipped with an ALT/VSI reselect, Marker Beacon Lights, Audio Panel, either a Garmin 430 or 530, (the COMM1/NAV1 function is provided in the GPS unit), NAV2/COMM2 (KX 165 TSO), ADF (KR27) and a Flight Director/Autopilots (KFC 150). Optional avionics include EFS 40 or E500 (ELITE AHRS). iGATEs are also available with OEM Garmin GNS 430W, GNS 530W, GTN 650, GTN 750 or G1000. Using real Garmin equipment insures the highest fidelity of performance and the best navigation training transfer as possible.



## NAV/COMM

On the “COMM2/NAV2”, and the “ADF” receivers, the right window displays the stand by frequency and the left one displays the active frequency. Setting a frequency is done in the same way as on a real receiver. Use the rotary to count up or down the standby frequency. Pushing the double-arrow button will toggle (“flip-flop”) the frequencies. Each receiver may be switched on and off individually. The receivers are initially all on. The identification code of the currently selected “NAV” station will be audible over the computer’s built-in speaker, or external speakers, when the ID button is pressed.

When the RAD button (Radial) on the NAV1 or NAV2 receiver is activated, the actual radial from the VOR station is displayed in place of the standby frequency. While in the radial mode, direct tuning of the active frequency is available using the methods described above. There is, of course, no radial available when an ILS frequency is tuned.

## ADF RECEIVER

The Automatic Direction Finder Receiver (ADF) in ELITE selects a Non Directional Beacon (NDB) in the frequency range  $\pm 600$  Hz around the frequency set. This means that, for example, an NDB with a frequency of 371.5 kHz may be received with the ADF set to either 371 or 372.

NOTE: When a receiver is tuned to a frequency, the closest NAVaid with this frequency is received. When two facilities in the same area have identical frequencies, ELITE will show a dialog box to select the desired one.

## MARKER RECEIVER

The Marker Receiver can be switched to LO, HI and TEST. The

LO selection may be made to set marker reception to low sensitivity, i.e. markers will only receive data at a short distance, such as during the approach. The marker lamp panel consists of the conventional: A lamp (white when lit, airway marker, inner marker), O lamp (blue when lit, outer marker), M lamp (amber when lit, middle marker).

When passing a marker, the appropriate identification code is heard while the corresponding marker lamp flashes. The duration of the marker reception as well as the reception range depends on the type of marker.

## TRANSPONDER

Transponder KN 67A

Push button to right to change number IDENT Change transponder mode (Click mouse on knob and drag left or right to activate transponder features)

The Transponder is a radio transmitter and receiver which operates on radar frequencies. Receiving ground radar interrogations at 1030 MHz, it returns a coded response of pulses to ground-based radar on frequency of 1090 MHz.



## USING THE COURSE/HEADING PANEL

NOTE: Instrumentation may vary among trainers

The Course/Heading is used to set course and headings using either the HSI/ flight director (if equipped) or using VOR #1 OBS and VOR #2.OBS. In addition, the altimeter setting and radar altimeter bug may also be set as necessary. The course and heading bug knobs are found in the typical location on the instrument panel by the corresponding instrument. The MDI is for the Magnetic Deviation Indicator.

### Course/Heading Control Panel





Controls VOR OBS #1



es between HSI and OBS #1



s the course in OBS #2



Sets the Altimeter



## iPAD Configuration Page

The ELITE iGATE ATD has a built-in WiFi network that will allow you to connect your iPad to the ELITE master computer and sync with certain popular navigation and utility Apps. The iGATE is currently compatible with the following iPad applications:

- Foreflight
- Garmin Pilot
- Skycharts Pro
- FS widgets
- iGMap
- FSWidgets EFB
- Airtrack
- OZ Runways



### How to Configure Your iPad Application

1. Go to the “iPad Configure” screen by right-clicking on your map or instrument panel and selecting “iPad Configure”, or use the “ALT-Y” shortcut. The following screen will appear:

AirTrack	Foreflight	FSWidgets	OzRunways	SkyCharts
Communicating: All <input type="button" value="SEND"/> Multicast <input type="button" value="SEND"/> Devices in List <input type="button" value="SEND"/> New List Single <input type="button" value="SEND"/> <input type="button" value="CONFIG"/>	Communicating: Broadcast <input type="button" value="SEND"/> Broadcast: 192.168.002.255 Devices in List <input type="button" value="SEND"/> <input type="button" value="CONFIG"/>	Communicating: Computer IP Address: 192.168.002.138 Port: 54320 <input type="button" value="SET"/> <input type="button" value="DEFAULT"/>	Communicating: Broadcast <input type="button" value="SEND"/> Broadcast: 192.168.002.255 Devices in List <input type="button" value="SEND"/> <input type="button" value="CONFIG"/>	Communicating: Multicast <input type="button" value="SEND"/> Devices in List <input type="button" value="SEND"/> <input type="button" value="CONFIG"/>
	Port: 49002 Pos. Intv: 1000 ms <input type="button" value="SET"/> Alt. Intv: 100 ms <input type="button" value="DEFAULT"/>	Port: 49002 Interval: 50 ms <input type="button" value="SET"/> <input type="button" value="DEFAULT"/>	Port: 49002 Interval: 50 ms <input type="button" value="SET"/> <input type="button" value="DEFAULT"/>	Port: 49100 Interval: 1000 ms <input type="button" value="SET"/> <input type="button" value="DEFAULT"/>


Notice that each column of this screen is for a different supported iPad application. You only need to work within the iPad application you are using. You can use more than one iPad application, however, if you choose to.

**NOTE: A WIFI network is required! If security controls prohibit the use of WIFI in your location, a cable can be used to transmit iGATE data to the iPad. Please check with ELITE technical support personnel for availability and pricing.**

## Foreflight® Connectivity

Given the overwhelming popularity of this app, we will show you how to connect Foreflight and the iGATE from the iPad side of the application:

1. Make sure your iPad is on the correct Wi-Fi network.
2. Launch the iGATE software.
3. Go to the iPad Configure Page on the IOS or “ALT-Y”.
4. Press “Send” under the Broadcast Foreflight column.
5. Start Foreflight® on your iPad.
6. Press the “more” button”, then go to devices. ELITE will appear as a “device”.
7. Select the ELITE device and enable it. The ELITE device will display as connected.



Additional information and illustrations on connecting other apps can be found on the ELITE website:

<http://support.flyelite.com/wp-content/uploads/2015/10/iPad-Configuration.pdf>

# ELECTRONIC FLIGHT INSTRUMENTATION SYSTEM

## EFS 40 PILOT'S GUIDE




**NOTE:** EFS 40 is an optional instrumentation system available for iGATE systems. EFS appropriate masks and control heads are included.



**EFS Control Module**

For the purposes of this manual, the intent is not to provide a complete pilot's guide but to give an introduction to and abbreviate commands associated with the EFS 40. For complete instructions, refer to Bendix/King EFS 40/50 Pilot's Guide Manual.



\*SW 08 OR LATER  
 †NO SELECTION BEGINNING WITH SW 08


## Abbreviate Operation of the EFS Control Panel

The EFS 40/50 uses a defined color set which aids the pilot in interpreting displayed information. A brief summary of the color set is as follows:


Warnings	Red
Cautions/Abnormal Source	Yellow
Scales and associated figures	White
On-side approach and navigation data	Green
Cross-side NAV data	Yellow
On-side non-approach navigation data (LNAV)	Cyan
On-side commanded data	Green
Cross-side commanded data	Yellow
Selected heading, DME HOLD annunciation	Orange
Selected source	Matches NAV data color
Selected active route/flight plan	Green
Cross-side selected active route/flight plan	Yellow
Held DME distance display	White

EFS Color Standards

## EFS Symbol Definition



# EADI Symbolology Definition





# SHORTCUT CHECKLIST

## GENERAL SHORT CUTS

'ALT' + 'W'	Map Page
'ALT' + 'W'	Weather Page (clouds / visibility)
'ALT' + 'S'	Malfunctions Page
'ALT' + 'C'	Control Page (time of day, weight, fuel)
'E'	Engine sound on / off

## FREEZE SHORT CUTS (see FNPT-Control Page)

'ALT' + 'F'	Normal Freeze
'Control' + 'ALT' + 'Shift' + 'G'	Position Freeze
'Control' + 'ALT' + 'Shift' + 'H'	Altitude Freeze
'Control' + 'ALT' + 'Shift' + 'F'	Fuel Freeze

## CREATE TEMPORARY STATEFILES (SNAPSHOTS, see FNPT control page)

'Control' + 'ALT' + '1' to '9'	Save snapshot 1 to 9
'Control' + 'ALT' + 'Shift' + '1' to '9'	Recall snapshot 1 to 9

These snapshots are only available during a session.

## MAP "DUMP" for Printout after Session

'ALT' + 'P'	A screenshot of the map is stored in the subdirectory "Dump" in file system (C:\ProgramFiles\Elite\Pilot 8\Dump"). The file name is "Dump YYYY-MM-DD-hh-mm-ss.bmp". This file can be printed after the session without interfering with the simulation
-------------	--

## MODIFY SIMULATION SPEED

'Control' + 'ALT' + 'S'	Reduce simulation speed
'Control' + 'ALT' + 'F'	Increase simulation speed

## MAP SHORT CUTS

'I'	Zoom In
'O'	Zoom Out
'N'	Zoom to 100 % (Normal zoom level)
'C'	Center A/C symbol on map
'ALT' + 'J'	Fail / activate station. After pressing 'ALT' + 'J', click on station which should be failed / activated. Press 'ALT' + 'J' again to get back normal cursor.



Use arrow keys on keyboard to move map.

## Changing HDG, ALT and IAS on the MAP page

HDG change

ALT change

IAS change

Left mouse click on knob, move mouse diagonal to the left.

Left mouse click on knob, move mouse diagonal.. Click once with mouse on knob to change ALT in steps of 500ft.

Left mouse click on knob, move mouse diagonal. Click once with mouse on knob to change IAS in steps of 10kts.

**DO NOT USE RIGHT MOUSE CLICK WHEN FLYING**

# ELITE iGate Configuration Matrix

as of 8 May 2018

Available Aircraft	Controls		Control Type		Instrumentation: Analog					GPS				Instrumentation: TAA	
	Single	Dual	Spring	C/L	DG	RMI	H SI	EFIS	AHRS-E500	ELITE 430W	ELITE 530W	Garmin GNS	Garmin GTN	Garmin G1000	
ANALOG:															
Cessna 172R	✓	✓	✓		✓	✓	-	-	✓	✓	✓	✓	✓	-	
Cessna 172RG	✓	✓	✓		✓	✓	✓	-	✓	✓	-	✓	✓	-	
Cessna 182S	✓	✓	✓		✓	✓	✓	-	-	✓	-	✓	✓	-	
Beech Bonanza A36	✓	✓	✓		✓	✓	✓	-	-	✓	✓	✓	✓	-	
Piper Arrow IV	✓	✓	✓		✓	✓	✓	-	✓	✓	-	✓	✓	-	
Piper Archer III	✓	✓	✓		✓	✓	-	-	-	✓	✓	✓	✓	-	
Beech Duchess 76	✓	✓	✓		✓	✓	✓	-	-	✓	-	✓	✓	-	
Beech Baron 58	✓	✓	✓		✓	✓	✓	-	-	✓	-	✓	✓	-	
Piper Seneca III	✓	✓	✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	-	
Beech King Air B200	✓	✓	✓		-	✓	✓	✓	✓	✓	-	✓	✓	-	
Pilatus PC-12	✓	✓	✓		-	✓	✓	✓	-	✓	✓	✓	✓	-	
GLASS (Garmin G1000):															
Cessna 172S G1000	✓	✓	✓		-	-	-	-	-	-	-	-	-	✓	
Cessna 182 G1000	✓	✓	✓		-	-	-	-	-	-	-	-	-	✓	
Diamond DA40	✓	✓	✓		-	-	-	-	-	-	-	-	-	✓	
Diamond DA42	✓	✓	✓		-	-	-	-	-	-	-	-	-	✓	
Beech Baron G58	✓	✓	✓		-	-	-	-	-	-	-	-	-	✓	

